


TM_MULTI_R32_3D INV_EU_S_NA_2202

MULTI SPLIT TYPE R32 INVERTER CONTROL

TECHNICAL MANUAL






Table of Contents

1.	Spec	ifications
	1.	Model Reference
	2.	Functions
	3.	General Specifications
	4.	Indoor Unit Combination
	5.	Dimensional Drawings
	6.	Air Velocity and Temperature Distributions
	7.	Electrical Wiring Diagrams
	8	Refrigerant Cycle Diagrams
	9.	Noise Criterion Curves
	10.	Electrical Characteristics
	11.	Static Pressure
2.	Prod	uct Features 108
	1.	Operation Modes and Functions
	2.	Remote Controller Functions
3.	Insta	allation
	1.	Installation Overview
	2.	Location Selection
	3.	Indoor Unit Installation
	4.	Outdoor Unit Installation
	5.	Drainage Pipe Installation
	6.	Refrigerant Pipe Installation
	7.	Vacuum Drying and Leakage checking

Page

8. Additional Refrigerant Charge

Table of Contents

Page

- 9. Engineering of Insulation
- 10. Engineering of Electrical Wiring
- 11. Test Operation

- 1. Introduction
- 2. Charts for friction losses in round ducts
- 3. Dynamic losses
- 4. Corresponding relation between Rectangular duct and Round duct
- 5. Method for duct calculation
- 6. Unit conversion
- 7. Recommended outlet velocity for different occasions

Specifications

Contents

1.	Model Reference	5
2.	Functions	6
3.	General Specifications	8
4.	Indoor Unit Combination	28
5.	Dimensional Drawings	30
6.	Air Velocity and Temperature Distributions	42
7.	Electrical Wiring Diagrams	66
8	Refrigerant Cycle Diagrams	84
9.	Noise Criterion Curves	89
10.	Electrical Characteristics	103
11.	Static Pressure	105

1. Model Reference

Refer to the following table to determine the specific indoor and outdoor unit model number of your purchased equipment.

In	door Unit	Outdoor Unit	Power Supply
	MTIU-07HWFNX-QRD0W		
	MTIU-07HWFNX-QRD0W(GA)		
A6 Duct type	MTIU-09HWFNX-QRD0W(GA)		
A6 Duct type	MTIU-09HWFNX-QRD0W	M2OG-14HFN8-Q M2OD-18HFN8-Q	
	MTIU-12HWFNX-QRD0W	M2OC-18HFN8-Q M3OF-21HFN8-Q	1Ph, 220- 240V~, 50Hz
	MTIU-18HWFNX-QRD0W	M3OF-27HFN8-Q M3OE-27HFN8-Q M4OE-28HFN8-Q	
	MCA3I-07HRFNX-QRD0	M4OB-36HFN8-Q M5OD-42HFN8-Q M5OE-42HFN8-Q M2OH-14HFN8-Q M2OE-18HFN8-Q	
	MCA3U-07HRFNX-QRD0W(GA)		
	MCA3U-09HRFNX-QRD0W(GA)	M3OG-21HFN8-Q M3OA-27HFN8-Q	
Compact Cassette type	MCA3I-09HRFN8-QRD0		
	MCA3U-12HRFNX-QRD0W		
	MCA3U-18HRFNX-QRD0W		

Inc	door Unit	Outdoor Unit	Power Supply
	MSAFBU-07HRDNX-QRD0GW		
	MSAFBU-09HRDN8-QRD0GW		
Wall mounted type- Forest	MSAFBU-12HRDN8-QRD0GW		
	MSAFCU-18HRFN8-QRD0GW		
	MSAFDU-24HRFN8-QRD0GW	M2OG-14HFN8-Q M2OD-18HFN8-Q	
	MSABAU-09HRFN8-QRD0GW	M20C-18HFN8-Q	
	MSABBU-12HRFN8-QRD0GW	M3OF-21HFN8-Q	
Wall mounted type-Aurora	MSABDU-18HRFN8-QRD0GW	M3OF-27HFN8-Q	
	MSABEU-24HRFN8-QRD0GW	M3OE-27HFN8-Q	
	MSAEBU-09HRFN8-QRD6GW	M4OE-28HFN8-Q M4OB-36HFN8-Q M5OD-42HFN8-Q	1Ph, 220- 240V~, 50Hz
	MSAEBU-12HRFN8-QRD0GW		
Wall mounted type-All Easy	MSAECU-18HRFN8-QRD0GW	M50E-42HFN8-Q	
	MSAEDU-24HRFN8-QRD0GW	M2OH-14HFN8-Q	
	MSAGAU-09HRFNX-QRD0GW	M2OE-18HFN8-Q	
	MSAGBU-09HRFN8-QRD1GW(GA)	M3OG-21HFN8-Q M3OA-27HFN8-Q	
	MSAGBU-12HRFNX-QRD0GW		
Wall mounted type-XTREME	MSAGBU-12HRFN8-QRD1GW(GA)		
	MSAGCU-18HRFNX-QRD0GW		
	MSAGDU-24HRFN8-QRD0GW		

2. Functions

Functions Model	A6 Duct type	Compact Cassette type
Standard filter	0	•
Flange	0	Х
Healthy filter	Х	Х
Drainage pump	0	•
IDU auxiliary electric heater	Х	Х
Infrared wired controller (KJR-12B, KJR-90A)	•	0
485 wired controller (KJR-120C, KJR-120G2)	0	0
2 cores non-polarity wired controller (KJR-120G)	0	0
Wifi	0	0
XYE port for central controller	•	•
Alarm output terminal	•	•
Remote on/off terminal	•	•
Golden Fin(Outdoor unit)	•	•

Note:

•: Standard

O: Optional

X: Not available

Functions Model	All Easy	Aurora	Forest	XTREME
High Density Filter	•	•	•	•
Cold Catalyst Filter	•	•	•	•
Fire Proof	•	٠	•	•
Turbo	٠	٠	•	•
Sleep	٠	٠	•	•
Auto-restart	٠	٠	•	•
Timer	٠	٠	•	•
super ionizer	●(9k~18k)/ O(24k)	Х	Х	0
horizontal louver autoswing	•	•	•	•
2 ways piping connection	•	•	•	•
H-shaped installation plate	Х	٠	•	•
Monolithic installation plate	0	0	0	0
louver position memory function	•	٠	•	•
follow me	0	0	0	0
ECO	0	•	0	•
Remote on/off terminal	0	0	Х	0
Alarm output terminal	0	Х	Х	0
XYE port for centrol control&weekly timer	0	0	Х	0
wired controller(simplex KJR- 12B,etc.)	0	0	0	0
wired controller(duplex KJR-120G/ TF-E,non-polarity)	0	Х	Х	0
WIFI	0	0	0	0
Golden Fin(Outdoor unit)	•	•	•	•

•: Standard

O: Optional

X: Not available

	Indoor model		MTIU-07HWFNX-QRD0W	MTIU-09HWFNX-QRD0W	MTIU-12HWFNX-QRDOW	MTIU-18HWFNX-QRD0W
Pov	ver supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	7000	9000	12000	18000
Cooling	Input	W	170	180	185	200
	Current	A	1.0	1.1	1.1	1.3
	Capacity	Btu/h	8000	10000	13000	19000
Heating	Input	W	170	180	185	200
	current	A	1.0	1.1	1.1	1.3
	Model		ZKFN-55-8-22	ZKFN-55-8-22	ZKFN-55-8-22	ZKFN-160-8-1-2
	Qty		1	1	1	1
Indoor fan motor	Input	W	130.0	130.0	130.0	90.0
	Capacitor	uF	/	/	/	/
	Speed(Hi/Mi/Lo)	r/min	1080/920/790	1080/920/790	1170/1030/850	1650/1300/1000
	a.Number of rows	3.0	3.0	3	3	3
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.4	1.4	1.4	1.4
Indoor coil	d.Fin type (code)		Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube
	f.Coil length x height x width	mm	526x210x40.11	526x210x40.11	526x210x40.11	695x252x40.11
	g.Number of circuits		4	4	4	4
Indo	or air flow (Hi/Mi/Lo)	m3/h	500/340/230	500/340/230	600/480/300	880/650/350
ESP	Rated	Pa	25	25	25	25
ESP	Range	Pa	0-40	0-40	0-60	0-100
Indoor s	ound pressure level (Hi)	dB(A)	40/34.5/27.5	40/34.5/27.5	40/34.5/27.5	41.5/38/33
Indoor	sound power level (Hi)	dB(A)	58	58	59	59
	Dimension(W*D*H)	mm	700x506x200	700x506x200	700x506x200	880x674x210
Indoor unit	Packing (W*D*H)	mm	860x540x275	860x540x275	860x540x275	1070x725x280
	Net/Gross weight	Kg	18/22	18/22	18/22	24.3/29.6
	Design pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7
Drair	nage water pipe dia.	mm	OD Φ 25	ODΦ25	ODΦ25	ODΦ25
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф12.7(1/4"/1/2")
	Controller		Wired Control	Wired Control	Wired Control	Wired control
Оре	eration temperature	°C	17~30	17~30	17~30	17~30
De ese temperature	Cooling	°C	17~32	17~32	17~32	17~32
Room temperature	Heating	°C	0~30	0~30	0~30	0~30

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

3. General Specifications

Notes:

1) Capacities are based on the following conditions:

- Cooling(T1): Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB
 - -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
 - -Interconnecting Piping Length 5m
 - Level Difference of Zero.
- 2) Capacities are Net Capacities.
- 3) Due to our policy of innovation some specifications may be changed without notification.

	Indoor model		MTIU-07HWFNX- QRD0W(GA)	MTIU-09HWFNX- QRD0W(GA)	MCA3U-07HRFNX- QRD0W(GA)	MCA3U-09HRFNX- QRD0W(GA)
Pow	er supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	7000	9000	7000	9000
Cooling	Input	W	170	180	40	40
Ĩ	Current	А	1.0	1.1	0.18	0.18
	Capacity	Btu/h	8000	10000	7500	10000
Heating	Input	W	170	180	40	40
	current	А	1.0	1.1	0.18	0.18
	Model		ZKFN-55-8-22	ZKFN-55-8-22	ZKFP-46-8-1	ZKFP-46-8-1
	Qty		1	1	1	1
Indoor fan motor	Input	W	130.0	130.0	45	45
	Capacitor	uF	/	/	-	-
Ì	Speed(Hi/Mi/Lo)	r/min	1050/900/820	1170/1030/850	600/520/460	600/520/460
Ì	a.Number of rows	3.0	3.0	3	1.0	1.0
ĺ	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37	21x13.37
Ì	c.Fin spacing	mm	1.4	1.4	1.3	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)	Hydrophilic aluminum	Hydrophilic aluminum(Golden)
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,innergroove tube
ĺ	f.Coil length x height x width	mm	526x210x40.11	526x210x40.11	1380x210x13.37	1380x210x13.37
	g.Number of circuits		4	4	2	2
Indoo	or air flow (Hi/Mi/Lo)	m3/h	500/340/230	500/340/230	540/500/460	540/500/460
	Rated	Ра	25	25	/	/
ESP	Range	Ра	0-40	0-40	/	/
Indoor so	ound pressure level (Hi)	dB(A)	40/34.5/27.5	40/34.5/27.5	37.5/33.5/31.5	38/34.5/33
Indoor s	sound power level (Hi)	dB(A)	56	57	53	53
	Dimension(W*D*H)(body)	mm	700x506x200	700x506x200	570x570x260	570x570x260
	Packing (W*D*H)(body)	mm	860x540x275	860x540x275	662x662x317	662x662x317
	Dimension(W*D*H)(panel)	mm	/	/	647x647x50	647x647x50
Indoor unit	Packing (W*D*H)(panel)	mm	/	/	715x715x123	715x715x123
	Net/Gross weight(body)	kg	17.8/21.5	17.8/21.5	14.5/17.5	14.5/17.5
	Net/Gross weight(panel)	kg	/	/	2.5/4.5	2.5/4.5
Design pressure		MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7
Drainage water pipe dia.		mm	ODΦ25	OD Φ 25	OD Φ 25	ΟDΦ25
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8"
	Controller		Wired Control	Wired Control	Remote Control	Remote Control
Ope	ration temperature	°C	17~30	17~30	17~30	17~30
i	Cooling	°C	17~32	17~32	17~32	17~32
Room temperature	Heating	°C	0~30	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.

- Heating: Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB
 - -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB
 - Interconnecting Piping Length 5 m
 - Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

	Indoor model		MCA3I-07HRFNX-QRD0	MCA3I-09HRFN8-QRD0	MCA3U-12HRFNX-QRD0W	MCA3U-18HRFNX-QRD0W
Pow	er supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
Capacity		Btu/h	7000	9000	12000	18000
Cooling	Input	W	40	40	40	102
	Current	А	0.18	0.18	0.18	0.44
	Capacity	Btu/h	7500	10000	14000	18500
Heating	Input	W	40	40	40	102
	current	A	0.18	0.18	0.18	0.44
	Model		ZKFP-46-8-1	ZKFP-46-8-1	ZKFP-46-8-1	ZKFP-46-8-1
	Old Model		WZDK46-38G	WZDK46-38G	WZDK46-38G	WZDK46-38G
	Qty		1	1	1	1
Indoor fan motor	Input	W	45	45	45	45
	Capacitor	uF	-	-	-	/
	Speed(Hi/Mi/Lo)	r/min	600/520/460	600/520/460	700/580/500	720/625/540
	a.Number of rows	3.0	1.0	1.0	2	2
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.3	1.3	1.3	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)	Hydrophilic aluminum(Golden)
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,innergroove tube	Φ7,innergroove tube	Φ7,innergroove tube
	f.Coil length x height x width	mm	1380x210x13.37	1380x210x13.37	1360x210x26.74	1360x210x26.74
	g.Number of circuits		2	2	4	4
Indoo	or air flow (Hi/Mi/Lo)	m3/h	580/500/450	580/500/450	617/504/415	680/560/500
Indoor so	ound pressure level (Hi)	dB(A)	37.0/33.0/31.5	38/33/29	41/37/34	44/42/41
Indoor s	sound power level (Hi)	dB(A)	51	53	58	56
	Dimension (W x Dx H)(body)	mm	570x570x260	570x570x260	570x570x260	570x570x260
	Packing (W x Dx H)(body)	mm	662x662x317	662x662x317	662x662x317	662x662x317
Indoor unit	Dimension (W x Dx H)(panel)	mm	647x647x50	647x647x50	647x647x50	647x647x50
indoor unit	Packing (W x Dx H)(panel)	mm	715x715x123	715x715x123	715x715x123	715x715x123
	Net/Gross weight(body)	kg	14.5/17.3	14.5/17.3	16.2/21.4	16.2/21.4
	Net/Gross weight(panel)	kg	2.5/4.5	2.5/4.5	2.5/4.5	2.5/4.5
C	Design pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7
Drainage water pipe dia.		mm	ODΦ25	ODΦ25	ODΦ25	ODΦ25
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф12.7(1/4"/1/2")
	Controller		Remote Control	Remote Control	Remote Control	Remote control
Oper	ration temperature	°C	17~30	17~30	17~30	17~30
Room tempera-	Cooling	°C	17~32	17~32	17~32	17~32
ture	Heating	°C	0~30	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.
- 2) Capacities are Net Capacities.
- 3) Due to our policy of innovation some specifications may be changed without notification.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

	Indoor model		MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW	MSAFBU-12HRDN8-QRD0GW
Powe	er supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	7000	9000	12000
Cooling	Input	W	20	20	20
	Current	А	0.09	0.09	0.09
	Capacity	Btu/h	8000	10000	13000
Heating	Input	W	20	20	20
	current	А	0.09	0.09	0.09
	Model		YKFG-13-4-38L	YKFG-13-4-38L	YKFG-13-4-38L
	Input	w	40	40	40
Indoor fan motor	Capacitor	uF	1.2	1.2	1.2
	Speed(Hi/Mi/Lo)	r/min	1030/850/700	1030/850/700	1130/950/750
	a.Number of rows	3.0	2.0	2.0	2.0
	b.Tube pitch(a)x row pitch(b)	mm	19.5x11.6	19.5x11.6	19.5x11.6
	c.Fin spacing	mm	1.2	1.2	1.2
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum
	e.Tube outside dia.and type	mm	Φ5,innergroove tube	Φ5,innergroove tube	Φ5,innergroove tube
	f.Coil length x height x width	mm	595x273x23.2	595x273x23.2	595x273x23.2
	g.Number of circuits		4	4	4
Indoo	r air flow (Hi/Mi/Lo)	m3/h	520/460/340	520/460/340	600/500/360
Indoor so	ound pressure level (Hi)	dB(A)	40/30/26/21	40/30/26/21	40/34/26/22
Indoor s	ound power level (Hi)	dB(A)	54	53	53
	Dimension(W*D*H)	mm	805x194x285	805x194x285	805x194x285
Indoor unit	Packing (W*D*H)	mm	870x270x360	870x270x360	870x270x360
	Net/Gross weight	Kg	7.5/9.7	7.5/9.7	7.5/9.7
D	esign pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Φ6.35/Φ9.52(1/4"/3/8")	Φ6.35/Φ9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")
	Controller	Wired Control	Remote Control	Remote Control	Remote Control
Oper	ation temperature	°C	17~30	17~30	17~30
Room tempera-	Cooling	°C	17~32	17~32	17~32
ture	Heating	°C	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

- -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB - Interconnecting Piping Length 5 m
- Level Difference of Zero.

2) Capacities are Net Capacities.

- Level Difference of Zero.

-Interconnecting Piping Length 5m

3) Due to our policy of innovation some specifications may be changed without notification.

	Indoor model		MSAFCU-18HRFN8-QRD0GW	MSAFDU-24HRFN8-QRD0GW
F	Power supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50
	Capacity	Btu/h	18000	24000
Cooling	Input	W	34	62
	Current	А	0.15	0.28
	Capacity	Btu/h	19000	25000
Heating	Input	W	34	62
	current	А	0.15	0.28
	Model		ZKFP-30-8-3	ZKFP-58-8-1
Indoor fan motor	Input	W	36	58.0
Indoor fan motor	Capacitor	uF	/	/
	Speed(Hi/Mi/Lo)	r/min	1130 / 900 / 800	1150 / 1000 / 850
	a.Number of rows	3.0	2.0	2.0
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37
	c.Fin spacing	mm	1.2	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube
	f.Coil length x height x width	mm	750x294x26.74	780x315x26.74
	g.Number of circuits		3	4
In	door air flow (Hi/Mi/Lo)	m3/h	840/680/540	980/817/662
Indoo	or sound pressure level (Hi)	dB(A)	44/37/30/25	44.5/42/34.5/28
Indo	or sound power level (Hi)	dB(A)	55	59
	Dimension(W*D*H)	mm	957x213x302	1040x220x327
Indoor unit	Packing (W*D*H)	mm	1035x295x380	1120x405x310
	Net/Gross weight	Kg	10/13	12.3/15.8
	Design pressure	MPa	4.3/1.7	4.3/1.7
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Φ6.35/Φ12.7(1/4"/1/2")	Ф9.52/Ф15.9(3/8"/5/8")
	Controller	Wired Control	Remote control	Remote control
(Dperation temperature	°C	17~30	17~30
	Cooling	°C	17~32	17~32
Room temperature	Heating	°C	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

-Interconnecting Piping Length 5m

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

	Indoor model		MSABAU-09HRFN8-QRD0GW	MSABBU-12HRFNX-QRD0GW	MSABDU-18HRFNX-QRD0GW	MSABEU-24HRFNX-QRD0GW
Power	r supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	9000	12000	18000	25000
Cooling	Input	W	24	24	34	62
Heating	Current	A	0.11	0.11	0.15	0.28
	Capacity	Btu/h	10000	13000	19000	26000
Heating	Input	W	24	24	34	62
	current	А	0.11	0.11	0.15	0.28
	Model		ZKFP-20-8-6-7	ZKFP-20-8-6-7	ZKFP-30-8-3	ZKFP-58-8-1
Indoor fan motor	Input	W	50.0	50.0	36	58
	Capacitor	uF	/	/	/	/
	Speed(Hi/Mi/Lo)	r/min	1150/850/700	1100/1000/700	1100/800/700	1100/900/700
	a.Number of rows	3.0	2	2	2	2
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.3	1.3	1.2	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminium	Hydrophilic aluminium	Hydrophilic aluminium
	e.Tube outside dia. and type	mm	Φ7,Inner groove tube	Φ7,innergroove tube	Φ7,innergroove tube	Φ7,innergroove tube
	f.Coil length x height x width	mm	525x84x13.37+525x105x26.74 +525x105x26.74	605x210x26.74+605x84x26.74	750x210x26.74+ 750x126x26.74	820x210x26.74+ 820x126x26.74
	g.Number of circuits	1	2	2	4	4
Indoor	air flow (Hi/Mi/Lo)	m3/h	416/309/230	515/459/294	750/505/420	1020/830/640
Indoor sou	ind pressure level (Hi)	dB(A)	39/23/20	38/22/21	41/28/20	46/30/26
Indoor so	und power level (Hi)	dB(A)	54	56	58	62
	Dimension(W*D*H)	mm	722x187x290	802x189x297	965x215x319	1080x226x335
Indoor unit	Packing (W*D*H)	mm	790x270x375	875x285x380	1045x305x410	1155x415x320
	Net/Gross weight	Kg	7.3/9.7	8.2/10.7	10.8/14.1	12.9/16.5
Design pressure		MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7
Refrigerant piping Liquid side/ Gas side		mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Φ6.35/Φ9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")
	Controller	Wired Control	Remote Control	Remote Control	Remote Control	Remote Control
Opera	tion temperature	°C	17~30	17~30	17~30	17~30
Room tem-	Cooling	°C	17~32	17~32	17~32	17~32
perature	Heating	°C	0~30	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.

- Interconnecting Piping Length 5 m

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

	Indoor model		MSAEAU-09HRFNX-QRD0GW	MSAEBU-12HRFNX-QRD0GW	MSAECU-18HRFNX-QRD0GW	MSAEDU-24HRFNX-QRD0G
Powe	r supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	9000	12000	18000	25000
Cooling	Input	W	24	24	34	62
	Current	A	0.11	0.11	0.15	0.28
Capacity		Btu/h	10000	14000	19000	26000
Heating	Input	W	24	24	34	62
	current	А	0.11	0.11	0.15	0.28
	Model		ZKFP-20-8-6-7	ZKFP-20-8-6-7	ZKFP-30-8-3	ZKFP-58-8-1
Indoor fan	Input	W	50	50	36	58
motor	Capacitor	uF	/	/	/	/
	Speed(Hi/Mi/Lo)	r/min	1100/900/750	1100/900/750	1100/1000/800	1100/1000/800
	a.Number of rows	3.0	2.0	2.0	2.0	2.0
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.2	1.2	1.2	1.3
Indoor coil	d.Fin type (code)	İ	Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum
	e.Tube outside dia. and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube	Ф7,Inner groove tube
	f.Coil length x height x width	mm	598x84x13.37+598x105x26.74 +598x84x26.74	598x84x13.37+598x105x26.74 +598x84x26.74	750x189x26.74+ 750x105x26.74	820x189x26.74+ 820x126x26.74
	g.Number of circuits		2	2	3	5
Indoor	air flow (Hi/Mi/Lo)	m3/h	549/482/357	549/482/357	809/718/545	978/864/646
Indoor sou	und pressure level (Hi)	dB(A)	39.5/25.5/22.5	41.5/28/23 44.5/28.5/24		45.5/35.5/27
Indoor so	ound power level (Hi)	dB(A)	53	54	57	59
	Dimension(W*D*H)	mm	805x193x302	805x193x302	964x222x325	1106x232x342
ndoor unit	Packing (W*D*H)	mm	875x375x290	875x375x290	1045x405x310	1195x420x320
	Net/Gross weight	Kg	8.3/11	8.2/10.9	10.8/14.3	14.3/18.2
De	esign pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")
	Controller	Wired Control	Remote Control	Remote Control	Remote Control	Remote Control
Opera	tion temperature	°C	17~30	17~30	17~30	17~30
Room tem-	Cooling	°C	17~32	17~32	17~32	17~32
perature	Heating	°C	0~30	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

-Interconnecting Piping Length 5m

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

Page 15

- - -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB
 - Interconnecting Piping Length 5 m
 - Level Difference of Zero.

	Indoor model		MSAGAU-09HRFNX-QRD0GW	MSAGBU-09HRFN8-QRD1GW(GA)	MSAGBU-12HRFNX-QRD0GW
Pow	er supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity Btu/		9000	9000	12000
Cooling	Input	w	21	23	23
Current		A	0.09	0.10	0.10
	Capacity	Btu/h	10000	10000	13000
Heating	Input	W	21	23	23
	current	A	0.09	0.10	0.10
	Model		ZKFP-20-8-6-7	ZKFP-13-8-4	ZKFP-13-8-4
	Input	W	50	18.2	18.2
Indoor fan motor	Capacitor	uF	/	/	/
	Speed(Hi/Mi/Lo)	r/min	1050//700	1050/450	1050//700
	a.Number of rows		2	2	2
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.3	1.3	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube
	f.Coil length x height x width	mm	525x84x13.37+525x105x26.74+525x 105x26.74	605x210x26.74+605x105x26.74	605x210x26.74+605x105x26.74
	g.Number of circuits		2	2	2
Indoo	r air flow (Hi/Mi/Lo)	m3/h	460/330/260	510/360/300	530/400/350
Indoor so	ound pressure level (Hi)	dB(A)	37.0/32.0/22.0	37/0/22	37.0/32.0/22.0
Indoor s	ound power level (Hi)	dB(A)	54	55	55
	Dimension(W*D*H)	mm	726x210x291	835x295x208	835x208x295
Indoor unit	Packing (W*D*H)	mm	790x270x375	905x355x290	905x355x290
	Net/Gross weight	Kg	8.0/10.5	8.7/11.5	8.7/11.5
C	esign pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Φ6.35/Φ9.52(1/4"/3/8")	Ф6.35/Ф9.52(1/4"/3/8")
	Controller		Remote Control	Remote Control	Remote Control
Oper	ation temperature	°C	16~30	16~30	16~30
Room tempera-	Cooling	°C	16~32	16~32	16~32
ture	Heating	°C	0~30	0~30	0~30

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.
- 2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

- Heating: Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB
 - -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB
 - Interconnecting Piping Length 5 m
- Level Difference of Zero.

	indoor model		IVISAGBU-TZHKFINO-QKDTGW(GA)	IVISAGCU-TORKFINA-QKDUGW	IVISAGDU-24HKFINO-QKDUGVV
Powe	er supply (Indoor)	V- Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	12000	18000	24000
Cooling	Input	w	23	38	68
	Current	А	0.10	0.17	0.30
	Capacity	Btu/h	13000	19000	25000
Heating	Input	W	23	38	68
	current	A	0.10	0.17	0.30
	Model		ZKFP-13-8-4	ZKFP-30-8-3	ZKFP-58-8-1-5
	Input	W	18.2	36.0	58.0
ndoor fan motor	Capacitor	uF	/	/	/
	Speed(Hi/Mi/Lo)	r/min	1100/900/750	1150/1000/850	1150/1000/850
	a.Number of rows	3.0	2	2	2
	b.Tube pitch(a)x row pitch(b)	mm	21x13.37	21x13.37	21x13.37
	c.Fin spacing	mm	1.3	1.2	1.3
Indoor coil	d.Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum
	e.Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube	Φ7,Inner groove tube
	f.Coil length x height x width	mm	605x210x26.74+605x105x26.74	750x210x26.74+750x126x26.74	820x210x26.74+820x126x26.74
	g.Number of circuits		2	4	4
Indoo	r air flow (Hi/Mi/Lo)	m3/h	520/370/310	800/600/500	1090/770/610
Indoor so	ound pressure level (Hi)	dB(A)	38/33/22	41/37/31	46/37/34.5
Indoor s	ound power level (Hi)	dB(A)	60	56	62
	Dimension(W*D*H)	mm	835x208x295	969x241x320	1083x244x336
Indoor unit	Packing (W*D*H)	mm	905x355x290	1045x315x405	1155x415x315
	Net/Gross weight	Kg	8.7/11.3	11.2/14.6	13.6/17.3
D	esign pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7
Refrigerant piping	Liquid side/ Gas side	mm(inch)	Ф6.35/Ф9.52(1/4"/3/8")	Φ6.35/Φ12.7(1/4"/1/2")	Ф9.52/Ф15.9(3/8"/5/8")
	Controller	Wired Control	Remote Control	Remote Control	Remote Control
Oper	ation temperature	°C	16~30	16~30	16~30
Room tempera-	Cooling	°C	16~32	16~32	16~32

MSAGBU-12HRFN8-QRD1GW(GA)

L

Notes:

ture

1) Capacities are based on the following conditions:

Heating

Indoor model

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

0~30

°C

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB - Interconnecting Piping Length 5 m

- Level Difference of Zero.

0~30

MSAGCU-18HRFNX-QRD0GW

- -Interconnecting Piping Length 5m - Level Difference of Zero.
- 2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

Specifications

MSAGDU-24HRFN8-QRD0GW

0~30

	Outdoor model		M2OG-14HFN8-Q	M2OC-18HFN8-Q	M2OD-18HFN8-Q	
	Indoor unit combination		MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW	MSAFBU-09HRDN8-QRD0GW	
Power	Power Supply (Outdoor) V-P		220~240-1-50	220~240-1-50	220~240-1-50	
	Capacity	Btu/h	14000(6210~16400)	18000(3860~18000)	18000(3860~19000)	
Cooling	Input	W	1270(168~1714)	1630(150~2000)	1630(150~2000)	
	Rated current	A	5.52(0.73~9.3)	7.1(0.7~9.27)	7.1(0.7~9.21)	
	EER	W/W	3.2	3.24	3.24	
	Capacity	Btu/h	15000(5220~17400)	19000(6120~19000)	19000(6120~20000)	
Unation	Input	W	1185(265~1707)	1390(300~1670)	1390(300~1650)	
Heating	Rated current	A	5.15(1.15~9.4)	6.1(1.4~7.74)	6.1(1.4~7.41)	
	COP	W/W	3.71	4.01	4.01	
Max. i	input consumption	W	2650	2300	2850	
	Max. current	A	11.5	12	13	
	Model		KSN140D21UFZ	KSM135D23UFZ	KSN140D21UFZ	
	Туре		ROTARY	ROTARY	ROTARY	
	Brand		GMCC	GMCC	GMCC	
	Capacity	Btu/h	4385	4230	4385	
C	Input	W	1140	1080	1140	
Compressor	Rated current(RLA)	А	7.50	7.1	7.50	
	Locked rotor Amp(LRA)	A	/	/	/	
	Thermal protector position		/	/	/	
	Capacitor	μF	/	/	/	
	Refrigerant oil	ml	VG74 440	VG74/450	VG74 440	
	Model		ZKFN-34-8-1-3	ZKFN-40-8-1L-5	ZKFN-34-8-1-3	
	Qty		1	1	1	
Outdoor fan motor	Output	W	34	40.0	34	
	Capacitor	uF	/	/	/	
	Speed	r/min	850/750/650	850/750/650	850/750/650	
	Number of rows		1	2.0	2	
	Tube pitch(a)x row pitch(b)	mm	21x22	25.4x22	25.4x22	
	Fin spacing	mm	1.2	1.4	1.4	
Outdoor coil	Fin type (code)	i i	Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum	
	Tube outside dia.and type	mm	Φ7,Inner groove tube	Ф9.52,Inner groove tube	Φ9.52,Inner groove tube	
	Coil length x height x width	mm	870x504x22	860x508x44	860x508x44	
	Number of circuits		2	4	4	
Oi	utdoor air flow	m3/h	2200	2200	/	
Outdoor	sound pressure level	dB(A)	56	56	55.5	
Outdoo	or sound power level	dB(A)	64	64	65	
	Throttle type		EXV+Capillary	EXV+Capillary	EXV+Capillary	
	Dimension(W*D*H)	mm	800x333x554	800x333x554	800x333x554	
Outdoor unit	Packing (W*D*H)	mm	920x390x615	920x390x625	920x390x615	
	Net/Gross weight	Kg	31.8/34.9	36/39	35.5/38.5	
	Туре	-	R32	R32	R32	
efrigerant type	GWP	-	675	675	675	
	Charged quantity	Kg	1.1	1.3	1.25	

D	Design pressure		4.3/1.7	4.3/1.7	4.3/1.7
	Liquid side/ Gas side	mm(inch)	2 x Ф6.35/Ф9.52(1/4"/3/8")	2 x Φ6.35/Φ9.52(1/4"/3/8")	2 x Ф6.35/Ф9.52(1/4"/3/8")
	Max. length for all rooms	m	40	40	40
Refrigerant piping	Max. length for one indoor unit	m	25	25	25
	Max. height difference be- tween indoor and outdoor unit	m	15	15	15
	Max. height difference between indoor units	m	10	10	10
Ambient tem-	Cooling	°C	-15~50	-15~50	-15~50
perature	Heating	°C	-15~24	-15~24	-15~24

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

- Interconnecting Piping Length 5 m
- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

	Outdoor model		M3OE-27HFN8-Q	M3OF-21HFN8-Q	M3OF-27HFN8-Q
	Indoor unit combination		MSAFBU-09HRDN8-QRD0GW	MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW
Power Supply (Outdoor)		V-Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	27000(7370~27000)	21000(6619~23420)	27000(10100~29000)
Casling	Input	W	2440(200~3070)	1950(180~2240)	2450(235~3220)
Cooling	Rated current	А	10.6(0.9~13.5)	9.0(1.09~9.9)	13.7(2.2~14.3)
	EER	W/W	3.24	3.23	3.23
	Capacity	Btu/h	28800(6400~31500)	22500(5900~24740)	28000(6950~32000)
l la chie e	Input	W	2270(320~2850)	1780(325~1920)	2100(310~2890)
Heating	Rated current	А	10.0(1.4~12.5)	8.5(1.94~8.5)	12.5(2.5~12.9)
	COP	W/W	3.72	3.71	3.91
Max.	input consumption	W	3100	3300	3600
	Max. current	А	15	15.5	17.5
	Model		KTF235D22UMT	KSN140D21UFZ	KTM240D57UMT
	Туре		ROTARY	ROTARY	ROTARY
	Brand		GMCC	GMCC	GMCC
	Capacity	Btu/h	7650	4385	7715
C	Input	W	2065	1140	2085
Compressor	Rated current(RLA)	А	9.4	7.50	9.45
	Locked rotor Amp(LRA)	A	/	/	/
	Thermal protector position		/	/	/
	Capacitor	μF	/	/	/
	Refrigerant oil	ml	RB74A F/670	VG74 440	VG74 670
	Model		ZKFN-50-8-2	ZKFN-50-8-2-3	ZKFN-50-8-2-3
	Qty		1	1	1
Outdoor fan motor	Output	W	50	50	50
	Capacitor	uF	/	/	/
	Speed	r/min	850/750/600	750/650/550	850/650/550
	Number of rows		2	2	1
	Tube pitch(a)x row pitch(b)	mm	25.4x22	21x22	25.4x22
	Fin spacing	mm	1.4	1.2	1.4
Outdoor coil	Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum	Unhydrophilic aluminium
	Tube outside dia.and type	mm	Φ9.52,Inner groove tube	Φ7,Inner groove tube	Φ9.52,Inner groove tube
	Coil length x height x width	mm	730x660x44	730x651x44	730x660x22
	Number of circuits		4	4	4
Ċ	Outdoor air flow	m3/h	2700	/	/
Outdoo	or sound pressure level	dB(A)	59	57.5	59
Outdo	or sound power level	dB(A)	66	65	67
	Throttle type		EXV+Capillary	EXV+Capillary	EXV+Capillary
	Dimension(W*D*H)	mm	845x363x702	845x363x702	845x363x702
Outdoor unit	Packing (W*D*H)	mm	965x395x775	965x395x775	965x395x775
	Net/Gross weight	Kg	54.4/59.2	46.8/51.1	51.1/55.8
	Туре	-	R32	R32	R32
Refrigerant type	GWP	-	675	675	675
	Charged quantity	Kg	1.57	1.4	1.72

	Design pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7
	Liquid side/ Gas side	mm(inch)	3 x Ф6.35/Ф9.52(1/4"/3/8")	3 x Ф6.35/Ф9.52(1/4"/3/8")	3 х Ф6.35/Ф9.52(1/4"/3/8")
	Max. length for all rooms	m	60	60	60
	Max. length for one indoor unit	m	30	30	30
Refrigerant piping	Max. height difference between indoor and outdoor unit	m	15	15	15
	Max. height difference between indoor units	m	10	10	10
Ambient temperature	Cooling	°C	-15~50	-15~50	-15~50
Ambient temperature	Heating	°C	-15~24	-15~24	-15~24

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

-Interconnecting Piping Length 5m

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

4).For other combination, refer to the combination table.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

	Outdoor model		M4OE-28HFN8-Q	M4OB-36HFN8-Q	M50D-42HFN8-Q	M50E-42HFN8-Q
	Indoor unit combination		MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW	MSAFBU-09HRDN8-QRD0GW	MSAFBU-09HRDN8-QRD0GV
Power	Supply (Outdoor)	V-Ph-Hz	220~240-1-50	220~240-1-50	220~240-1-50	220~240-1-50
	Capacity	Btu/h	28000(8000~34200)	36000(12430~37000)	42000(10170~42000)	42000(10300~42000)
	Input	W	2550(204~3446)	3300(330~4250)	4320(280~4580)	3810(280~4650)
Cooling	Rated current	А	11(1.17~15)	15.0(1.5~18.5)	18.9(1.2~20.0)	16(1.4~20.7)
	EER	W/W	3.23	3.2	2.85	3.23
	Capacity	Btu/h	30000(8100~35800)	37000(9730~41000)	42000(9370~42000)	42000(11800~42000)
	Input	W	2050(431~3050)	2760(470~4210)	3100(510~4000)	3300(650~3800)
Heating	Rated current	А	9(2.55~13.3)	12.1(2.1~18.4)	13.5(2.2~17.6)	14.6(3.0~16.6)
	COP	W/W	4.0	3.93	3.97	3.73
Max. ir	nput consumption	W	4150	4600	4700	4700
Ν	Max. current	A	19	21.5	22	22
	Model		KTM240D57UMT	KTF310D43UMT	KTF310D43UMT	KTF310D43UMT
	Туре		ROTARY	ROTARY	ROTARY	ROTARY
	Brand		GMCC	GMCC	GMCC	GMCC
	Capacity	Btu/h	7715	10010	10010	10010
	Input	W	2085	2765	2765	2765
Compressor	Rated current(RLA)	A	9.45	5.38	5.38	5.38
	Locked rotor Amp(LRA)	A	/	/	/	/
	Thermal protector position		/	EXTERNAL	EXTERNAL	EXTERNAL
	Capacitor	μF	/	/	/	/
	Refrigerant oil	ml	VG74 670	VG74/1000	VG74/1000	VG74/1000
	Model		ZKFN-120-8-2	ZKFN-120-8-2	ZKFN-120-8-2	ZKFN-120-8-2
	Qty		1	1	1	1
Outdoor fan motor	Output	W	120	120	120	120
motor	Capacitor	uF	/	/	/	/
	Speed	r/min	900/750/600	900/750/600	900/750/600	900/750/600
	Number of rows		2	2.0	3.0	3
	Tube pitch(a)x row pitch(b)	mm	21x13.37	25.4x22	25.4x22	25.4x22
	Fin spacing	mm	1.4	1.3	1.3	1.3
Outdoor coil	Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum	Hydrophilic aluminum
	Tube outside dia.and type	mm	Φ7,Inner groove tube	Ф9.52,Inner groove tube	Ф9.52,Inner groove tube	Φ9.52,Inner groove tube
	Coil length x height x width	mm	1005x756x13.37+ 985x756x13.37	995x762x44	978x762x44+580x762x22	995x762x22+960x762x22+5 0x762x22
	Number of circuits		6	4	4	4
Ou	tdoor air flow	m3/h	/	4000	3850	3850
Outdoor	sound pressure level	dB(A)	61.5	61	64	64
Outdoor	sound power level	dB(A)	67	67	69	69
Т	hrottle type		EXV+Capillary	EXV+Capillary	EXV+Capillary	EXV+Capillary
	Dimension(W*D*H)	mm	946x410x810	946x410x810	946x410x810	946x410x810
Dutdoor unit	Packing (W*D*H)	mm	1090x500x885	1090x500x885	1090x500x885	1090x500x885
	Net/Gross weight	Kg	62.1/67.7	68.8/75.6	73.3/80.4	74.1/79.5
	Туре	-	R32	R32	R32	R32
Refrigerant type	GWP	-	675	675	675	675
-76-5	Charged quantity	Kg	2.1	2.1	2.4	2.9
De	sign pressure	MPa	4.3/1.7	4.3/1.7	4.3/1.7	4.3/1.7

	Liquid side/ Gas side	mm(inch)	4 x Φ6.35/3x Φ9.52+1xΦ12.7(4x1 /4"/3x3/8"+1x1/2")	4 x Φ6.35/3x Φ9.52+1xΦ12.7(4x1 /4"/3x3/8"+1x1/2")	5 x Φ6.35/4x Φ9.52+1xΦ12.7(5x1 /4"/4x3/8"+1x1/2")	5 x Φ6.35/4x Φ9.52+1xΦ12.7(5x1 /4"/4x3/8"+1x1/2")
	Max. length for all rooms	m	80	80	80	80
Refrigerant piping	Max. length for one indoor unit	m	35	35	35	35
	Max. height difference between indoor and outdoor unit	m	15	15	15	15
	Max. height difference between indoor units	m	10	10	10	10
Ambient	Cooling	°C	-15~50	-15~50	-15~50	-15~50
temperature	Heating	°C	-15~24	-15~24	-15~24	-15~24

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

- -Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB
- -Interconnecting Piping Length 5m
- Level Difference of Zero.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

- -Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB
 - Interconnecting Piping Length 5 m
- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

	Outdoor model		M2OH-14HFN8-Q	M2OE-18HFN8-Q
	Indoor unit combination		MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW
Power Supply (Outdoor)		V-Ph-Hz	220~240-1-50	220~240-1-50
	Capacity	Btu/h	14000(5100~17000)	18000(7800~19500)
	Input	w	1270(115~1672)	1635(690~2000)
Cooling	Rated current	A	5.8(1.12~7.35)	7.3(3.20~9.00)
	EER	W/W	3.23	3.23
	Capacity	Btu/h	15000(5200~17000)	19000(8200~19600)
	Input	w	1185(253~1592)	1500(600~1780)
Heating	Rated current	A	5.4(1.9~7.0)	6.6(2.80~7.95)
	СОР	W/W	3.71	3.71
Max	. input consumption	w	2750	3050
	Max. current	A	12	13.0
	Model	1 1	KSN140D58UFZ	KSN140D58UFZ
	Туре	1 1	ROTARY	ROTARY
	Brand	1 1	GMCC	GMCC
	Capacity	Btu/h	4315	4315
	Input	w	1090	1090
Compressor	Rated current(RLA)	A	7.15	7.15
	Locked rotor Amp(LRA)	A	/	/
	Thermal protector position		/	/
	Capacitor	μF	/	/
	Refrigerant oil	ml	ESTER OIL VG74 440	ESTER OIL VG74 440
	Model		ZKFN-34-10-1-3	ZKFN-34-10-1-3
	Qty	1 1	1	1
Outdoor fan motor	Output	w	34	34
	Capacitor	uF	/	/
	Speed	r/min	760/700/500	760/700/500
	Number of rows	1 1	1.0	2.0
	Tube pitch(a)x row pitch(b)	mm	21x22	21x22
	Fin spacing	mm	1.3	1.3
Outdoor coil	Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum
	Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ9.52,Inner groove tube
	Coil length x height x width	mm	870x504x44	860*504*44
	Number of circuits	1	2	4
	Outdoor air flow	m3/h	2100	2100
Outdo	or sound pressure level	dB(A)	56	54.0
Outdo	oor sound power level	dB(A)	64	65
	Throttle type		EXV+Capillary	EXV+Capillary
Outdoor unit	Dimension(W*D*H)	mm	805x330x554	805x330x554
	Packing (W*D*H)	mm	915x370x615	915x370x615
	Net/Gross weight	Kg	31.6/34.7	35.0/38.0
	Туре	-	R32	R32
Refrigerant type	GWP		675	675
5 - 1911 -	Charged quantity	Kg	1.1	1.25
	Design pressure	MPa	4.3/1.7	4.3/1.7

	Liquid side/ Gas side	mm(inch)	2 x Ф6.35/Ф9.52(1/4"/3/8")	2 x Ф6.35/Ф9.52(1/4"/3/8")
	Max. length for all rooms	m	40	40
	Max. length for one indoor unit	m	25	25
Refrigerant piping	Max. height difference between indoor and outdoor unit	m	15	15
	Max. height difference between indoor units	m	10	10
Andriantana	Cooling	°C	-15~50	-15~50
Ambient temperature	Heating	°C	-15~24	-15~24

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

-Interconnecting Piping Length 5m

- Level Difference of Zero.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

	Outdoor model		M3OG-21HFN8-Q	M3OA-27HFN8-Q
	Indoor unit combination	i	MSAFBU-07HRDNX-QRD0GW	MSAFBU-09HRDN8-QRD0GW
Power Supply (Outdoor)		V-Ph-Hz	220~240-1-50	220~240-1-50
	Capacity	Btu/h	21000(6800~22500)	27000(10850~28000)
	Input	w	1905(180~2200)	2450(290~3100)
Cooling	Rated current	A	8.3(1.8~10.0)	11.2(2.0~13.5)
	EER	W/W	3.23	3.23
	Capacity	Btu/h	22000(6800~22800)	28000(7800~29000)
	Input	w	1738(350~1800)	2210(370~2900)
Heating	Rated current	A	7.6(2.6~8.0)	10.1(2.4~13)
	COP	w/w	3.71	3.71
Ma	x. input consumption	w	3910	4100
	Max. current	A	17	18
	Model		KSN140D58UFZ	KTM240D57UMT
	Туре	1 1	ROTARY	Twin-ROTARY
	Brand	+	GMCC	GMCC
	Capacity	Btu/h	4315	7740
	Input	W	1090	2085
Compressor	Rated current(RLA)	A	7.15	9.45
	Locked rotor Amp(LRA)	A	/	/
	Thermal protector position		/	/
	Capacitor	μF	/	/
	Refrigerant oil	ml	ESTER OIL VG74 440	ESTER OIL VG74 670
	Model		ZKFN-80-8-3	ZKFN-80-8-3
	Qty	+ +	1	1
Outdoor fan motor	Output	w	80	80
	Capacitor	uF	/	/
		+ +	750/700/600	, 800/580
	Speed	r/min		
	Number of rows		1.6 21x22	2 21x13.37
	Tube pitch(a)x row pitch(b)	mm		
Outstand and the	Fin spacing	mm	1.3	1.3
Outdoor coil	Fin type (code)		Hydrophilic aluminum	Hydrophilic aluminum
	Tube outside dia.and type	mm	Φ7,Inner groove tube	Φ7,Inner groove tube
	Coil length x height x width	mm	900*609*22+540*609*22	900*609*22+865*609*22
	Number of circuits	24	5	6
	Outdoor air flow	m3/h	3000	3000
	por sound pressure level	dB(A)	58.0	58
Outd	oor sound power level	dB(A)	65	67
	Throttle type	<u> </u>	EXV+Capillary	EXV+Capillary
	Dimension(W*D*H)	mm	890x342x673	890x342x673
Outdoor unit	Packing (W*D*H)	mm	1030x438x750	1030x438x750
	Net/Gross weight	Kg	43.3/47.1	48/51.8
	Туре		R32	R32
Refrigerant type	GWP		675	675
	Charged quantity	Kg	1.5	1.85
	Design pressure	MPa	4.3/1.7	4.3/1.7

	Liquid side/ Gas side	mm(inch)	3 x Ф6.35/Ф9.52(1/4″/3/8″)	3 x Ф6.35/Ф9.52(1/4″/3/8″)
	Max. length for all rooms	m	60	60
	Max. length for one indoor unit	m	30	30
Refrigerant piping	Max. height difference between indoor and outdoor unit	m	15	15
	Max. height difference between indoor units	m	10	10
Ambient temperature	Cooling	°C	-15~50	-15~50
Ambient temperature	Heating	°C	-15~24	-15~24

1) Capacities are based on the following conditions:

Cooling(T1): - Indoor Temperature 27°C(80.6°F) DB /19 °C(66.2°F) WB

-Outdoor Temperature 35 °C(95°F) DB /24 °C(75.2°F) WB

-Interconnecting Piping Length 5m

- Level Difference of Zero.

Heating: - Indoor Temperature 20°C(68°F) DB / 15°C(59°F) WB

-Outdoor Temperature 7°C(44.6°F) DB / 6°C(42.8°F) WB

- Interconnecting Piping Length 5 m

- Level Difference of Zero.

2) Capacities are Net Capacities.

3) Due to our policy of innovation some specifications may be changed without notification.

4. Indoor Unit Combination

M2OG-14HFN8-Q, M2OH-14HFN8-Q

One Unit	Two	Units
7	7+7	9+9
9	7+9	9+12
12	7+12	
18		

M2OC-18HFN8-Q, M2OD-18HFN8-Q, M2OE-18HFN8-Q

One Unit	Two Units					
7	7+7	9+9				
9	7+9	9+12				
12	7+12	12+12				
18						

M3OF-21HFN8-Q, M3OG-21HFN8-Q

One Unit	Two	Units	Three Units			
7	7+7	9+9	7+7+7	7+9+9		
9	7+9	9+12	7+7+9	9+9+9		
12	7+12	9+18	7+7+12			
18	7+18	12+12				

M3OE-27HFN8-Q, M3OF-27HFN8-Q, M3OA-27HFN8-Q

One Unit		Two Units		Three Units			
7	7+7	7+18	9+18	7+7+7	7+7+7 7+9+12		
9	7+9	9+9	12+12	7+7+9	7+12+12	9+12+12	
12	7+12 9+12		12+18	7+7+12	9+9+9	12+12+12	
18				7+9+9			

M4OE-28HFN8-Q

One Unit		Two Units			Three Units		Four Units		
7	7+7	9+9	12+12	7+7+7	7+9+12	9+9+12	7+7+7+7	7+9+9+9	
9	7+9	9+12	12+18	7+7+9	7+9+18	9+9+18	7+7+7+9	7+9+9+12	
12	7+12	9+18	12+24	7+7+12	7+12+12	9+12+12	7+7+7+12	9+9+9+9	
18	7+18	9+24	18+18	7+7+18	9+9+9	12+12+12	7+7+9+9		
24	7+24			7+9+9					

M4OB-36HFN8-Q

One Unit		Two Units		Three Units				
7	7+7	9+9	12+12	7+7+7	7+9+12	7+18+18	9+12+18	
9	7+9	9+12	12+18	7+7+9	7+9+18	9+9+9	9+12+24	
12	7+12	9+18	12+24	7+7+12	7+9+24	9+9+12	9+18+18	
18	7+18	9+24	18+18	7+7+18	7+12+12	9+9+18	12+12+12	
24	7+24			7+7+24	7+12+18	9+9+24	12+12+18	
				7+9+9	7+12+24	9+12+12		

	Four Units										
7+7+7+7	7+7+9+12	7+9+9+12	9+9+9+12								
7+7+7+9	7+7+9+18	7+9+9+18	9+9+9+18								
7+7+7+12	7+7+12+12	7+9+12+12	9+9+12+12								
7+7+7+18	7+7+12+18	7+12+12+12	9+12+12+12								
7+7+9+9	7+9+9+9	9+9+9+9	12+12+12+12								

M50D-42HFN8-Q, M50E-42HFN8-Q

One Unit		Two Units		Three Units						
7	7+7	9+9 12+12		7+7+7	7+9+9	7+12+18	9+9+18	9+18+18		
9	7+9	9+12	12+18	7+7+9	7+9+12	7+12+24	9+9+24	12+12+12		
12	7+12	9+18	12+24	7+7+12	7+9+18	7+18+18	9+12+12	12+12+18		
18	7+18	9+24	18+18	7+7+18	7+9+24	9+9+9	9+12+18	12+12+24		
24	7+24			7+7+24	7+12+12	9+9+12	9+12+24	12+18+18		


	Four Units										
7+7+7+7	7+7+9+9	7+7+12+18	7+9+9+18	7+9+18+18	9+9+9+18	9+12+12+12					
7+7+7+9	7+7+9+12	7+7+12+24	7+9+9+24	7+12+12+12	9+9+9+24	9+12+12+18					
7+7+7+12	7+7+9+18	7+7+18+18	7+9+12+12	7+12+12+18	9+9+12+12	12+12+12+12					
7+7+7+18	7+7+9+24	7+9+9+9	7+9+12+18	9+9+9+9	9+9+12+18	12+12+12+18					
7+7+7+24	7+7+12+12	7+9+9+12	7+9+12+24	9+9+9+12	9+9+12+24						

	Five Units										
7+7+7+7+7	7+7+7+9+18	7+7+9+12+12	7+9+9+9+18	9+9+9+12+12							
7+7+7+7+9	7+7+7+12+12	7+7+9+12+18	7+9+9+12+12	9+9+12+12+12							
7+7+7+7+12	7+7+7+12+18	7+7+12+12+12	7+9+12+12+12								
7+7+7+7+18	7+7+9+9+9	7+7+12+12+18	9+9+9+9+9								
7+7+7+9+9	7+7+9+9+12	7+9+9+9+9	9+9+9+9+12								
7+7+7+9+12	7+7+9+9+18	7+9+9+9+12	9+9+9+9+18								

5. Dimensional Drawings

5.1 Indoor Unit

A6 Duct type





Capacity (Btu/h)	unit	А	В	с	D	E	F	G	н	I	J	к	L	М	H1	H2	W1	W2
71, 121,	mm	700	200	506	450	137	537	30	152	599	186	50	741	360	84	140	84	84
7k~12k	inch	27.56	7.87	19.92	17.72	5.39	21.14	1.18	5.98	23.58	7.32	1.97	29.17	14.17	3.31	5.51	3.31	3.31
1.01/	mm	880	210	674	600	140	706	50	136	782	190	40	920	508	78	148	88	112
18k	inch	34.65	8.27	26.54	23.62	5.51	27.8	1.97	5.35	30.79	7.48	1.57	36.22	20	3.07	5.83	3.46	4.41

G


L Sall

Compact Cassette type







Forest











ía	1		
	ſ		1
	Í		
		`	

Capacity(Btu/h)	unit	W(mm)	D(mm)	H(mm)
9k/12k	mm	805	194	285
	inch	31.7	7.6	11.2
18k	mm	957	213	302
	inch	37.7	8.4	11.9
24k	mm	1040	220	327
	inch	40.9	8.7	12.9

Aurora








Capacity(Btu/h)	W(mm)	D(mm)	H(mm)
9k	722	187	290
12k	802	189	297
18k	965	215	319
24k	1080	226	335

All Easy








O


D



Capacity(Btu/h)	W(mm)	D(mm)	H(mm)
9k/12k	805	193	302
18k	964	222	325
24k	1106	232	342

XTREME









Model	W(mm)	D(mm)	H(mm)
MSAGAU-09HRFNX-QRD0GW	726	210	291
MSAGBU-12HRFNX-QRD0GW			
MSAGBU-09HRFN8-QRD1GW(GA)	835	208	295
MSAGBU-12HRFN8-QRD1GW(GA)			
MSAGCU-18HRFNX-QRD0GW	969	241	320
MSAGDU-24HRFN8-QRD0GW	1083	244	336


5.2 Outdoor Unit


M2OG-14HFN8-Q, M2OC-18HFN8-Q, M2OD-18HFN8-Q








M3OF-21HFN8-Q, M3OE-27HFN8-Q, M3OF-27HFN8-Q















M4OE-28HFN8-Q, M4OB-36HFN8-Q













M50D-42HFN8-Q, M50E-42HFN8-Q













M2OH-14HFN8-Q, M2OE-18HFN8-Q










M3OG-21HFN8-Q, M3OA-27HFN8-Q





6. Air Velocity and Temperature Distributions

Compact Cassette type -7k, 9k &12k

Discharge Angle 30°


Cooling airflow velocity distributions






Compact Cassette type -7k, 9k &12k

Heating airflow velocity distributions




Heating temperature distributions




Compact Cassette type -7k, 9k &12k

Discharge Angle 60°


Cooling airflow velocity distributions






Compact Cassette type -7k, 9k &12k


Heating airflow velocity distributions






Discharge Angle 30°


Cooling airflow velocity distributions




Cooling temperature distributions



Heating airflow velocity distributions





Heating temperature distributions




Discharge Angle 60°

Cooling airflow velocity distributions






Heating airflow velocity distributions




Heating temperature distributions




XTREME-9k

Discharge Angle 58° Cooling airflow velocity distributions




Velocity Magnitude [m/s]




XTREME-9k

Discharge Angle 90°

Heating airflow velocity distributions







XTREME-12k

Discharge Angle 58°

Cooling airflow velocity distributions







XTREME-12k

Heating airflow velocity distributions

Discharge Angle 90°






XTREME-18k


Discharge Angle 50°

Cooling airflow velocity distributions






8



XTREME-18k

Discharge Angle 84°


Heating airflow velocity distributions



XTREME-24k


Discharge Angle 50°

Cooling airflow velocity distributions



Floor distance [m]

Cooling temperature distributions





Floor distance [m]

XTREME-24k

Discharge Angle 67°


Heating airflow velocity distributions






AURORA-9k

Discharge Angle 58° Cooling airflow velocity distributions




Velocity Magnitude [m/s]




AURORA-9k

Discharge Angle 90°

Heating airflow velocity distributions







AURORA-12k

Discharge Angle 58°

Cooling airflow velocity distributions







AURORA-12k

Discharge Angle 90°

Heating airflow velocity distributions







AURORA-18k

Discharge Angle 50°

Cooling airflow velocity distributions







AURORA-18k

Discharge Angle 84°


Heating airflow velocity distributions






AURORA-24k

Discharge Angle 50° Cooling airflow velocity distributions



Floor distance [m]

Cooling temperature distributions





Floor distance [m]

AURORA-24k

Discharge Angle 67° Heating airflow velocity distributions








7. Electrical Wiring Diagrams


8.1 Indoor unit


A6 Duct type

MTIU-07HWFNX-QRD0W, MTIU-09HWFNX-QRD0W











MTIU-07HWFNX-QRD0W(GA), MTIU-09HWFNX-QRD0W(GA), MTIU-18HWFNX-QRD0W


Compact Cassette type:

MCA3I-07HRFNX-QRD0, MCA3I-09HRFN8-QRD0



MCA3U-12HRFNX-QRD0W






MCA3U-07HRFNX-QRDOW(GA), MCA3U-09HRFNX-QRDOW(GA), MCA3U-18HRFNX-QRDOW


Wall mounted type

MSAFBU-07HRDNX-QRDOGW, MSAFBU-09HRDN8-QRDOGW, MSAFBU-12HRDN8-QRDOGW, MSAFCU-18HRFN8-QRDOGW, MSAFDU-24HRFNX-QRDOGW, MSAEBU-09HRFN8-QRD6GW MSAEBU-12HRFN8-QRDOGW, MSAECU-18HRFN8-QRD0GW, MSAEDU-24HRFN8-QRD0GW MSAGAU-09HRFNX-QRD0GW, MSAGBU-09HRFN8-QRD1GW(GA), MSAGBU-12HRFN8-QRD1GW(GA), MSAGBU-12HRFNX-QRD0GW, MSAGCU-18HRFNX-QRD0GW




MSABAU-09HRFN8-QRD0GW, MSABBU-12HRFN8-QRD0GW, MSABDU-18HRFN8-QRD0GW,


MSABEU-24HRFN8-QRD0GW, MSAGDU-24HRFN8-QRD0GW




8.2 Outdoor Unit


M2OG-14HFN8-Q










< Page 76 🕨







M3OF-21HFN8-Q, M3OF-27HFN8-Q












M4OB-36HFN8-Q



M50D-42HFN8-Q, M50E-42HFN8-Q


Specifications






Page 82

M3OG-21HFN8-Q, M3OA-27HFN8-Q




8. Refrigerant Cycle Diagrams




	Pipe Size (Diameter:ø)		Pip	ing length	(m)	Elovati	on (m)		
Model				Max		Elevation (m)		Additional	
Model	Gas	Liquid	Rated	Single	Total	IDU and ODU	Between IDUs	Refrigerant	
M2OG-14HFN8-Q									
M2OC-18HFN8-Q	2x9.52	2x6.35	15	25	40	15	10	12g/m	
M2OD-18HFN8-Q									


Note: For M2OC-18HFN8-Q, there is no Accumulator.




	Pipe Size (Diameter:ø)		Pip	ing length	(m)	Elevation (m)			
Model				Max				Additional	
Woder	Gas	Liquid	uid Rated Single Tota		Total	IDU and ODU	Between IDUs	Refrigerant	
M2OH-14HFN8-Q	2x9.52		1 5	25	40	1 ⊑	10	12 a/m	
M2OE-18HFN8-Q	2X9.52	2x6.35	15	20	40	15	10	12g/m	



	Pipe Size (Diameter:ø)		Pip	ing length	(m)	Flowation (m)			
Model				Max		Elevation (m)		Additional	
Woder	Gas	Liquid	Rated	d Single Total		IDU and ODU	Between IDUs	Refrigerant	
M3OF-21HFN8-Q									
M3OE-27HFN8-Q	3x9.52	3x6.35	22.5	30	60	15	10	12g/m	
M3OF-27HFN8-Q									



	Pipe Size (Diam	Pipin	g length	(m)	Floyat	ion (m)			
Model			Max		Eleval	.1011 (11)	Additional		
	Gas	Liquid	Rated	Single	Total	IDU and ODU	Between IDUs	Refrigerant	
M4OE-28HFN8-Q	3x9.52+1x12.7	4x6.35	30	35	80	15	10	12g/m	
M4OB-36HFN8-Q	3x9.52+1x12.7	4x6.35	30	35	80	15	10	12g/m	




	Pipe Size (Diam	Pipir	ng length	n (m)	Eloyat	tion (m)			
Model			Max		Eleva		Additional		
Woder	Gas	Liquid	Rated	Single	Total	IDU and ODU	Between IDUs	Refrigerant	
M5OD-42HFN8-Q	4x9.52+1x12.7	5x6.35	37.5	35	80	15	10	12g/m	
M50E-42HFN8-Q	4x9.52+1x12.7	5x6.35	37.5	35	80	15	10	12g/m	

9. Noise Criterion Curves

10.1 Indoor Unit

A6 Duct type



Notes:

-Sound measured at 1.5m away from the center of the unit.

-Data is valid at free field condition

-Data is valid at nominal operation condition


-Reference acoustic pressure OdB = 20µPa

-Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.


-The operating conditions are assumed to be standard.

MTIU-07HWFNX-QRD0W/MTIU-07HWFNX-QRD0W(GA) MTIU-09HWFNX-QRD0W/MTIU-09HWFNX-QRD0W(GA)


MTIU-12HWFNX-QRD0W







Compact Cassette type



Notes:

-Sound measured at 1.4m away from the noisiest location of the unit.

-Data is valid at free field condition

-Data is valid at nominal operation condition


-Reference acoustic pressure OdB = 20µPa

-Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.


-The operating conditions are assumed to be standard.

MCA3I-07HRFNX-QRD0/MCA3U-07HRFNX-QRD0W(GA) MCA3I-09HRFN8-QRD0/MCA3U-09HRFNX-QRD0W(GA)


MCA3U-12HRFNX-QRD0W







Wall mounted type



Notes:

-Sound measured at 1.0m away from the center of the unit.

-Data is valid at free field condition


-Data is valid at nominal operation condition

-Reference acoustic pressure OdB = 20µPa


-Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.

-The operating conditions are assumed to be standard.


MSAFBU-07HRDNX-QRD0GW MSAFBU-09HRDN8-QRD0GW




MSAFBU-12HRDN8-QRD0GW




MSAFCU-18HRFN8-QRD0GW




MSAFDU-24HRFNX-QRD0GW




MSABAU-09HRFN8-QRD0GW




MSABDU-18HRFN8-QRD0GW




MSABBU-12HRFN8-QRD0GW




MSABEU-24HRFN8-QRD0GW




MSAEBU-09HRFN8-QRD6GW




MSAECU-18HRFN8-QRD0GW




MSAEBU-12HRFN8-QRD0GW



MSAEDU-24HRFN8-QRD0GW




MSAGAU-09HRFNX-QRD0GW




MSAGBU-09HRFN8-QRD1GW(GA)



MSAGDU-24HRFN8-QRD0GW



9.2 Outdoor Unit



Note: $H= 0.5 \times height of outdoor unit$

Notes:

-Sound measured at 1.0m away from the center of the unit.

-Data is valid at free field condition

-Data is valid at nominal operation condition


-Reference acoustic pressure OdB=20µPa

-Sound level will vary depending on arrange off actors such as the construction (acoustic absorption coefficient) of particular room in which the equipment is installed.

-The operating conditions are assumed to be standard.


M2OG-14HFN8-Q






< Page 99 🕨


M2OD-18HFN8-Q




M3OF-27HFN8-Q




M3OF-21HFN8-Q




M3OE-27HFN8-Q





M4OE-28HFN8-Q






M50D-42HFN8-Q








M50E-42HFN8-Q


80
















M3OA-27HFN8-Q

NC-70

NC-60

NC-50

NC-40

NC-30

NC-20

10. Electrical Characteristics

		Indoor Unit	t	P	ower Supp	у	IF	M
Model	Phase	Hz	Voltage	MCA	MOP	MFA	kW	FLA
MTIU-07HWFNX-QRD0W				/	/	/	0.055	1.11
MTIU-07HWFNX-QRD0W(GA)				/	/	/	0.055	1.11
MTIU-09HWFNX-QRD0W(GA)				/	/	/	0.055	1.11
MTIU-09HWFNX-QRD0W				/	/	/	0.055	1.11
MTIU-12HWFNX-QRD0W				/	/	/	0.055	1.11
MTIU-18HWFNX-QRD0W				/	/	/	0.16	1.48
MCA3I-07HRFNX-QRD0				/	/	/	0.046	0.146
MCA3U-07HRFNX-QRD0W(GA)				/	/	/	0.046	0.146
MCA3U-09HRFNX-QRD0W(GA)				/	/	/	0.046	0.146
MCA3I-09HRFN8-QRD0				/	/	/	0.046	0.146
MCA3U-12HRFNX-QRD0W				/	/	/	0.046	0.146
MCA3U-18HRFNX-QRD0W				/	/	/	0.046	0.146
MSAFBU-07HRDNX-QRD0GW				/	/	/	0.013	0.17
MSAFBU-09HRDN8-QRD0GW				/	/	/	0.013	0.17
MSAFBU-12HRDN8-QRD0GW	1	50	220-240	/	/	/	0.013	0.17
MSAFCU-18HRFN8-QRD0GW				/	/	/	0.03	0.148
MSAFDU-24HRFNX-QRD0GW				/	/	/	0.058	0.4
MSABAU-09HRFN8-QRD0GW				/	/	/	0.02	0.16
MSABBU-12HRFN8-QRD0GW				/	/	/	0.02	0.16
MSABDU-18HRFN8-QRD0GW				/	/	/	0.03	0.275
MSABEU-24HRFN8-QRD0GW				/	/	/	0.058	0.4
MSAEBU-09HRFN8-QRD6GW				/	/	/	0.02	0.16
MSAEBU-12HRFN8-QRD0GW				/	/	/	0.02	0.16
MSAECU-18HRFN8-QRD0GW				/	/	/	0.03	0.27
MSAEDU-24HRFN8-QRD0GW				/	/	/	0.058	0.4
MSAGAU-09HRFNX-QRD0GW			/	/	/	0.02	0.16	
MSAGBU-09HRFN8-QRD1GW(GA)				/	/	/	0.013	0.047
MSAGBU-12HRFNX-QRD0GW				/	/	/	0.013	0.047
MSAGBU-12HRFN8-QRD1GW(GA)			/	/	/	0.013	0.047	
MSAGCU-18HRFNX-QRD0GW				/	/	/	0.03	0.275
MSAGDU-24HRFN8-QRD0GW				/	/	/	0.058	0.4

	Ou	Outdoor Unit		Power Supply		Compressor		OFM		
Model	Phase	Hz	Voltage	MCA	MFA	MSC	RLA	Qty	kW	FLA
M2OG-14HFN8-Q				11.5	20	-	7.5	1	0.034	0.39
M2OC-18HFN8-Q				12	20	-	7.1	1	0.04	0.7
M2OD-18HFN8-Q				13	20	-	7.5	1	0.058	0.39
M3OF-21HFN8-Q				15.5	20	-	7.5	1	0.05	0.55
M3OE-27HFN8-Q				15	30	-	9.4	1	0.05	0.55
M3OF-27HFN8-Q	1	50	220-240	17.5	22	-	9.45	1	0.05	0.55
M4OE-28HFN8-Q				19	30	-	9.45	1	0.12	1.21
M4OB-36HFN8-Q				21.5	30	-	5.38	1	0.12	1.39
M50D-42HFN8-Q				22	30	-	5.38	1	0.12	1.39
M50E-42HFN8-Q				22	30	-	5.38	1	0.12	1.39
M2OH-14HFN8-Q				12	20	-	7.15	1	0.034	0.89
M2OE-18HFN8-Q				13	20	-	7.15	1	0.034	0.89
M3OG-21HFN8-Q				17	20	-	7.15	1	0.08	0.88
M3OA-27HFN8-Q				18	30	-	9.45	1	0.08	0.88

Notes:

MCA: Minimum Circuit Amperes (A)

MFA: Maximum Fuse Amperes (A)

MSC: Maximum Starting Current

RLA: Rated Load Amperes (A)

IFM: Indoor Fan Motor


OFM: Outdoor Fan Motor


FLA: Full Load Amperes (A)


kW: Fan motor rated output(kW)

11. Static Pressure

7K/9K









.imit

12K

18K





Page 107

Product Features


Contents

1.	Displa	ay Function	109
2.	Opera	113	
	2.1	Abbreviations	113
	2.2	Safety Features	113
	2.3	Fan	114
	2.4	Cooling Mode	114
	2.5	Heating Mode (Heat pump models)	114
	2.6	Auto Mode	114
	2.7	Drying Mode	115
	2.8	Timer Function	115
	2.9	Sleep Function	115
	2.10	Forced Operation Function	115
	2.11	Auto-Restart	116
	2.12	Follow Me	116
	2.13	Drain Pump Control	116
	2.14	Mode Conflict	116
3.	Remo	ote Controller Functions	117
	3.1	Infrared Wireless Remote Controller	117
	3.2	LCD Wired Remote Controller	123
	3.3	Centralized Controller	135
	3.4	Using the wire controller to set external static pressure	136
	3.5	Using the wire controller to set airflow rate	

1. Display Function


Unit display functions

Wall mounted type-Foreset:



Note: Please select the display function according to your purchase product.

Wall mounted type-Aurora:



(E)

Display		Function	
Ø		Fresh(available on select units only)	
ECO		ECO function (available on select units only)	
• 🖛		Lights up in different colour according to the operation mode(some units):	
'		Under COOL and DRY mode, it displays as cool colour.Under HEAT mode, it displays as warm colour.	
$\widehat{\cdot}$		when Wireless Control feature is activated(some units)	
88	Temperature value	Temperature	
	(3s)	Activation of Timer ON, Fresh, Swing, Turbo, or Silent	
	(3s)	Cancellation of Timer OFF, Fresh, Swing, Turbo, or Silent	
	dF	Defrost	
	cF	Warming in heating mode	
		Self-clean (available on select units only)	
	FP	Heating in room temperature under 8°C	

Note: Please select the display function according to your purchase product.


Wall mounted type-All Easy:

	fresh timer run Display A	fresh timer run Display B	
	fresh	When Fresh feature is activated(some units)	
	timer run	When TIMER is set When the unit is on	
		WiFi control (available on select units only)	
	Set temperature value Room temperature	Temperature Temperature (fan and Drying mode)	
		Activation of Timer ON, Fresh, Swing, Turbo, or Silent	
	(3s)	Activation of Timer OFF or cancellation of Fresh, Swing, Turbo, or Silent	
	dF	Defrost(Heat pump units)	
88	cF	Activation of anti-cold wind in heating mode	
	50	Self-clean (available on select units only)	
	FP	Heating in room temperature under 8°C	
	set temperature gradually illuminates to in one second interval	ECO function (available on select units only)	

Note: Please select the display function according to your purchase product.

Wall mounted type-XTREME






Display A

Display B


Display		Function
fresh		Fresh(available on select units only)
defrost		Defrost
run		When the unit is on
timer		When TIMER is on
$\widehat{\cdot}$		WiFi control (available on select units only)
88	Temperature value	Temperature
00		Activation of Timer ON, Fresh, Swing, Turbo, or Silent
		Cancellation of Timer OFF, Fresh, Swing, Turbo, or Silent
	dF	Defrost
		Active Clean(For Inverter split type) or self-cleaning(For Fixed-speed type)
	FP	Heating in room temperature under 8°C

Note: Please select the display function according to your purchase product.

A6 Duct type:



Compact Cassette type:



2. Operation Modes and Functions

2.1 Abbreviation

Unit element abbreviations

Abbreviation	Element
T1	Indoor room temperature
T2	Coil temperature of evaporator middle
T2B	Coil temperature of evaporator outlet(It is located in outdoor unit)
Т3	Coil temperature of condenser
T4	Outdoor ambient temperature
T5	Compressor discharge temperature
TS	Setting temperature
Tsc	Adjusted setting temperature

2.2 Safety Features

Open Circuit/Disconnection Sensor Protection

Automatic shutoff based on fan speed

For A6 Duct type,

If a fault occurs on the air volume regulator or the regulator enters protection mode, it sends the error message CF and an instruction to reduce fan speed to the master. The message and the instruction can be inquired with the remote controller or the wired controller. (Fault and protection information are displayed for one minute). After a fault occurs, the master unit shows the error code E3 and the fault count for one minute.

If the fault occurs three times, then the fan is unable to resolve the problem independently. External shutdown by a remote controller, wired controller, or central controller must be used to clear the fan fault and fault count. The fan runs normally for 5 minutes while clearing fault count.

For other types,

If the indoor fan speed registers below 300RPM for an extended period of time, it shuts off and restarts in 30 seconds. If this happens 3 times, the unit ceases operation and the corresponding error code is displayed on the indoor unit.

If outdoor fan speed registers below 100RPM or higher than 2400RPM for an extended period of time, the unit ceases operation and the corresponding error code is displayed on the indoor unit and outdoor unit.

Indoor fan delayed operation

- When the unit starts, the louver is automatically activated and the indoor fan will operate after a period of 7 seconds.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

Zero crossing detection error protection(For Forest series)

If AC can not detect zero crossing signal for 4 minutes or the zero crossing signal time interval is not correct, the unit will stop and the LED will display the failure. The correct zero crossing signal time interval should be between 6-13ms.

Compressor three-minute delay at restart

Compressor functions are delayed for up to one minute upon the first startup of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

Inverter module protection

The inverter module has an automatic shutoff mechanism based on the unit's current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit and the unit ceases operation.

Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds a certain level for a period of time, the compressor ceases operation.

Oil return

Running rules:

1. If the compressor frequency keeps lower than setting frequency for setting time, the AC will rise the frequency to setting frequency for setting time and then resume to former frequency.

2. The EXV will keep 300p while the indoor units will keep the current running mode.

If the outdoor ambient is higher than setting frequency during the oil return, the AC quit oil return.

2.3 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor cease operation.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to high, medium, low, , auto or 1%-100%.
- The louver operations are identical to those in cooling mode.
- Auto fan in fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 24°C.

2.4 Cooling Mode

2.4.1 Indoor Fan Control

- In cooling mode, the indoor fan operates continuously. The fan speed can be set to high, medium, low, auto or 1%-100%.
- The auto fan acts according to the value of T1-TS.

For MCA3U-18HRFNX-QRD0W, MCA3U-07HRFNX-QRD0W(GA), MCA3U-09HRFNX-QRD0W(GA), MTIU-07HWFNX-QRD0W(GA), MTIU-09HWFNX-QRD0W(GA), the auto fan acts according to the value of T1-Tsc.

2.4.2 Outdoor Fan Control

• The outdoor fan is controlled by T4.

2.4.3 Evaporator Temperature Protection

When T2<4°C for 250 seconds or T2<0°C, the compressor and outdoor fan cease operation and resume to normal when T2>8°C and the time of protection is no less than 3 minutes.

2.4.4 Condenser Temperature Protection

When condenser temperature is more than setting value, the compressor ceases operations.

2.5 Heating Mode(Heat pump models)

2.5.1 Indoor Fan Control

- When the compressor is on, the fan speed can be set to high, medium, low, or auto. And the anti-cold wind function has the priority.
- The auto fan acts according to the value of T1-Ts.

For MCA3U-18HRFNX-QRD0W, MCA3U-07HRFNX-QRD0W(GA), MCA3U-09HRFNX-QRD0W(GA), MTIU-07HWFNX-QRD0W(GA), MTIU-09HWFNX-QRD0W(GA), the auto fan acts according to the value of T1-Tsc.

2.5.2 Outdoor Fan Control

• The outdoor fan is controlled by T4.

2.5.3 Defrosting mode

- The unit enters defrosting mode according to the value of temperature of T3 and the value range of temperature change of T3 and also the compressor running time.
- If any one of the following items is satisfied, the defrosting will finish and the machine will turn to normal heating mode.
 - T3 rises to be higher than TCDE1°C.
 - T3 keeps to be higher than TCDE2°C for 80 seconds.
 - The machine has run for 10 minutes in defrosting mode.

2.5.4 Evaporator Temperature Protection

When the evaporator temperature exceeds a preset protection value, the compressor and outdoor fan cease operations, the outdoor fan motor ceases operation 30 seconds later.


2.5.5 Prevent Over-Heating

In heating mode, when the indoor unit has no capacity requirement due to indoor room temperature increased, the Indoor fan will run in super breeze. (Anti-cold wind function has the priority)

2.6 Auto Mode

- This mode can be selected with the remote controller and the temperature setting can be adjusted between 17°C~30°C
- For MCA3U-07HRFNX-QRD0W(GA), MCA3U-09HRFNX-QRD0W(GA):

In auto mode, the machine selects cooling, heating or fanonly mode on the basis of T1,Ts and T4.



In auto mode, the machine selects cooling, heating, or fanonly mode on the basis of $\bigtriangleup T$ ($\bigtriangleup T$ =T1-Ts).

For MCA3U-18HRFNX-QRD0W, MTIU-07HWFNX-QRD0W(GA), MTIU-09HWFNX-QRD0W(GA):

ΔΤ	Running mode
ΔT>3°C	Cooling
-3°C≤ΔT≤3°C	Fan-only
ΔT<-3°C	Heating*

For other models:

ΔΤ	Running mode
ΔT>2°C	Cooling
-2°C≤ΔT≤2°C	Fan-only
ΔT<-2°C	Heating*

Heating*: In auto mode, cooling only models run the fan.

- Indoor fans run at the auto fan speed of the relevant mode.
- The louver operates the same as in relevant mode.
- If the machine switches mode between heating and cooling, the compressor pauses for a certain period of time intermittently and then selects a mode based on T1-Ts.
- If the setting temperature is modified, the machine selects a new running function.

2.7 Drying Mode

- Indoor fan speed is fixed at low and cannot be changed.
- Low indoor room temperature protection
- In drying mode, if room temperature is lower than 10°C, the indoor fan will stop and not resume until room temperature exceeds 12°C.
- All protections are activated and operate the same as they do in cooling mode.
- The louver operates the same as in cooling mode.

2.8 Timer Function

- The timing range is 24 hours.
- Timer On. The machine turns on automatically at the preset time.
- Timer Off. The machine turns off automatically at the preset time.
- Timer On/Off. The machine turns on automatically at the preset On Time, and then turns off automatically at the preset Off Time.

- Timer Off/On. The machine turns on automatically at the preset Off Time and then turns off automatically at the preset On Time.
- The timer does not change the unit operation mode. If the unit is off now, it does not start up immediately after the "timer off" function is set. When the setting time is reached, the timer LED switches off and the unit running mode remains unchanged.
- The timer uses relative time, not clock time

2.9 Sleep Function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
- When cooling, the temperature rises 1°C (to not higher than 30°C) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed to auto speed.
- When heating, the temperature decreases 1°C (to not lower than 17°C) every hour. After 2 hours, the temperature stops decreasing and the indoor fan is fixed at auto speed. Anti-cold wind function takes priority.

2.10 Forced operation function

• Forced cooling mode:

The compressor and outdoor fan continue to run and the indoor fan runs at rated speed. After running for 30 minutes, the AC will switch to auto mode with a preset temperature of 24°C

• Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of 24°C.

- When any one of indoor units runs in forced cooling, it is designated as the master forced cooling unit. Other indoor units act as the slave forced cooling units. The slave forced cooling units cannot exit forced cooling mode until the master forced cooling unit does so. They then switch to cooling mode in low fan with the temperature set at 24°C.
- Forced defrosting mode:
 - In the forced cooling mode (single heat engine for forced auto mode), press and hold the forced key for 5 seconds after release, immediately enter the forced frosting mode.
 - When any one of indoor units runs in forced defrosting mode, the indoor fan is off and other indoor fans are off. The outdoor unit

operates forced defrosting.

2.11 Auto-Restart

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings (not including sleep mode) and, in the case of a sudden power failure, will restore those setting automatically within 3 minutes after power returns.
- If the unit was in forced cooling mode, it will run in this mode for 30 minutes and turn to auto mode with temperature set to 24°C.
- If there is a power failure while the unit is running, the compressor starts 3 minutes after the unit restarts. If the unit was already off before the power failure, the compressor starts 1 minute after the unit restarts.

2.12 Follow Me (Optional)

- If you press "Follow Me" on the remote, the indoor unit will beep. This indicates the follow me function is active.
- Once active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the unit's temperature setting.

2.13 Drain Pump Control (Optional)

- Use the water-level switch to control drain pump.
- The system checks the water level every 5 seconds.
 - When the A/C operates in cooling (including auto cooling) or forced cooling mode, the pump begins running immediately and continuously until cooling stops.
 - If the water level increases up to the control point, the LED displays an alarm code and the drain pump opens and continually monitors the water level. If the water level falls and LED alarm code is no longer displayed (drain pump close delay is 1 minute), the unit goes back into its last mode. Otherwise, the entire system (including the pump) stops and the LED displays an alarm again after 3 minutes.

2.14 Mode Conflict

- The indoor units can not work cooling mode and heating at same time.
- Heating mode has a priority.

(1) Definition

	Cooling mode	Heating Mode	Fan	Off
Cooling mode	No	Yes	No	No
Heating Mode	Yes	No	Yes	No
Fan	No	Yes	No	No
Off	No	No	No	No

No: No mode conflict;

Yes: Mode conflict

(2) Unit action

- In case of one Indoor unit working in cooling mode or fan mode, and another indoor unit is set to heating mode, the indoor unit working in cooling mode or fan mode will change to off. The outdoor unit will change to heating mode after compressor stop 3 minutes.
- In case of one Indoor unit working in heating mode, and another indoor unit is set to cooling mode or fan mode, the indoor unit setting to cooling mode or fan mode will change to stand by. The outdoor unit will continue working in heating mode.
- If heating mode stops (not including the indoor unit in heating mode reaching the set temperature), 3 minutes after the outdoor unit restarts and works in

cooling mode or fan-only mode.

Product Features

Page 116

3. Remote Controller Functions

→ AUTO → COOL→ DRY→ HEAT → FAN


3.1 Infrared Wireless Remote Controller

3.1.1 RG51Q1/BGE(Standard for cassette)

Remote Controller Specifications

Model	RG51Q1/BGE
Rated Voltage	3.0V (Dry batteries R03/ LR03×2)
Reaching Distance	8m
Environment Temperature Range	-5°C ~60°C (23°F ~140°F)

Buttons and Functions



1. TEMP UP A Button: Push this button to increase the indoor temperature setting in 1 C increments to 30 C

2. TEMP DOWN▼Button : Push this button to decrease the indoor temperature setting in 1 ℃ increments to 17 ℃.

3. MODE Button: Once pressing, running mode will be selected in the following sequence:

NOTE: No heating mode for cool only type unit.

4. SWING Button: Used to stop or start horizontal louver movement. The louver will swing up and down automatically if push this button.

5. SWING HButton: Used to stop or start vertical louver movement.

AIR DIRECTION Button: Used to set the desired up/down air flow direction. The louver changes 6 degree in angle for each press.

6. RESET Button(inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings.

7. ON/OFF Button: For turning on or turning off the air conditioner.

8. FAN SPEED Button: Fan speed will be selected in following sequence once pressing this button:

→ AUTO→ LOW→ MED→ HIGH

9. TIME ON Button: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

10. ECO Button: Select this function during the sleeping time. It can maintain the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only .

NOTE: While the unit is running under Energy-saving mode, it would be cancelled if press MODE, FAN SPEED or ON/OFF button.

11. TIME OFF Button: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.


12. CH Button(inner located): Press this recessed button to shift the mode between Cooling only and Cooling & Heating according to the feature of the machine. The factory default setting mode is Cooling & Heating. For example, the unit you purchased is Cooling only models, please press this recessed button with a needle of 1mm to shift the operation mode.

3.1.2 R51M/E(Standard for Forest series)

Remote Controller Specifications

Model	R51M/E
Rated Voltage	3.0V (Dry batteries R03/ LR03×2)
Reaching Distance	8m
Environment Temperature Range	-5 °C ~60 °C (23 °F ~140 °F)

Buttons and Functions



1. TEMP DOWN \checkmark Button : Push this button to decrease the indoor temperature setting in 1 °C increments to 17 °C.

2. TEMP UP A Button: Push this button to increase the indoor temperature setting in 1 C increments to 30 C

3. MODE Button: Once pressing, running mode will be selected in the following sequence:

NOTE: No heating mode for cool only type unit.

4. SWING Button: Push this switch button to activate auto swing feature of the horizontal louver. Push it again to stop.

5. RESET Button (inner located): Once the recessed

RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings.

6. AIR DIRECTION Button: Press this button to change the swing angle of the louver. The swing angle of the louver is 6 degree for each press. When the louver swing at a certain angle which would affect the cooling and heating effect of the air conditioner, it would automatically change the swing direction . No symbol will appear in the display area when press this button. (Not applicable to units without this function).

7. LED DISPLAY Button: Press this button to clear the digit display in the air conditioner, press it again to activate it (Not available for the units without LED display window).

8. FAN SPEED Button: Fan speed will be selected in following sequence once pressing this button:

 \vdash AUTO \rightarrow LOW \rightarrow MED \rightarrow HIGH

9. ON/OFF Button: For turning on or turning off the air conditioner.

10. TIME ON Button: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

11. SLEEP Button: Press this button to go into the Energy-Saving operation mode. Press it again to cancel. This function is only can be used on COOL, HEAT and AUTO mode and maintain the most comfortable temperature for you.

12. TIME OFF Button: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

13. LOCK Button(inner located): When you press the recessed LOCK button, all current settings are locked in and the remote controller does not accept any operation except that of the LOCK. Press again to cancel the LOCK mode.


14. TURBO Button: Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature at cooling or heating operation in the shortest time(if the indoor unit does not support this function, there is no corresponding operation happened when pressing this button.)

3.1.3 RG51F1/E(Standard for Aurora series)

Remote Controller Specifications

Model	RG51F1/E
Rated Voltage	3.0V (Dry batteries R03/ LR03×2)
Reaching Distance	8m
Environment Temperature Range	-5°C ~60°C (23°F ~140°F)

Buttons and Functions



1. TEMP UP \blacktriangle Button: Push this button to increase the indoor temperature setting in 1 °C increments to 30 °C

2. TEMP DOWN \checkmark Button : Push this button to decrease the indoor temperature setting in 1 °C increments to 17 °C.

3. MODE Button: Once pressing, running mode will be selected in the following sequence:

AUTO --- COOL--- DRY---- HEAT ---- FAN

NOTE: No heating mode for cool only type unit.

4. SWING [↑] Button: Used to stop or start horizontal louver movement or set the desired up/down air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the louver will swing up and down automatically.

5. ECO Button: Used to enter the energy efficient mode. Under cooling mode, press this button, the remote controller will adjust the temperature automatically to 24°C, fan speed of Auto to save energy(but only if the set temperature is less than 24°C). If the set temperature is between 24°C and 30°C, press the ECO button, the fan speed will change to Auto, the set temperature will remain unchanged.

NOTE: Pressing the TURBO and SLEEP button, modifying the mode or adjusting the set temperature to less than 24°C will stop ECO operation.

Under ECO operation, the set temperature should be 24°C or more. it may result in insufficient cooling. If you feel uncomfortable, just press the ECO button again to stop it.

6. SWING \leftrightarrow Button: Used to stop or start vertical louver movement and set the desired left/right air flow direction. The vertical louver changes 6 degree in angle for each press.

7. RESET Button (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings.

8. LED DISPLAY Button: Disable/Active indoor screen Display. When pushing the button, the indoor screen display is cleared, press it again to light the display.

9. ON/OFF Button: Operation starts when this button is pressed and stops when the button is pressed again.

10. FAN SPEED Button: Fan speed will be selected in following sequence once pressing this button:

 \vdash AUTO \rightarrow LOW \rightarrow MED \rightarrow HIGH

11. TIME ON Button: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

12. TIME OFF Button: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

13. LOCK Button(inner located): When you press the recessed LOCK button, all current settings are locked in and the remote controller does not accept any operation except that of the LOCK. Press again to cancel the LOCK mode.

14. TURBO Button: Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature at cooling or heating operation in the shortest time(if the


indoor unit does not support this function, there is no corresponding operation happened when pressing this button.)

3.1.4 RG51I55/BGEF(Standard for All Easy series)

Remote Controller Specifications

Model	RG51I55/BGEF
Rated Voltage	3.0V (Dry batteries R03/ LR03×2)
Reaching Distance	8m
Environment Temperature Range	-5°C ~60°C (23°F ~140°F)

Buttons and Functions



1. TEMP DOWN \blacktriangledown Button : Push this button to decrease the indoor temperature setting in 1 \odot increments to 17 \odot .

2. TEMP UP \triangleq Button: Push this button to increase the indoor temperature setting in 1 °C increments to 30 °C

3. MODE Button: Once pressing, running mode will be selected in the following sequence:

→ AUTO → COOL → DRY → HEAT → FAN-

NOTE: No heating mode for cool only type unit.

4. SWING 1 Button: Used to stop or start horizontal louver

movement or set the desired up/down air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the louver will swing up and down automatically.

5. SLEEP Button: Press this button to go into the Energy-Saving operation mode. Press it again to cancel. This function is only can be used on COOL, HEAT and AUTO mode and maintain the most comfortable temperature for you.

6. SWING \leftrightarrow Button: Used to stop or start vertical louver movement and set the desired left/right air flow direction. The vertical louver changes 6 degree in angle for each press.

7. SELF CLEAN/FRESH Button: Press this button under COOL or DRY mode, the self clean function is activated. Under SELF CLEAN mode, the air conditioner will automatically clean and dry the evaporator and keep it as fresh for the next operation.

Hold down this button for at least 2 seconds to activate/ cancel FRESH feature.When the FRESH function is initiated, the Ionizer/Plasma Dust Collector(depending on models) is energized and will help to remove pollen and impurities from the air.

8. FOLLOW ME Button: Push this button to initiate the Follow Me feature, the remote display is actual temperature at its location. The remote control will send this signal to the air conditioner every 3 minutes interval until press the Follow Me button again. The air conditioner will beep to indicate the Follow Me feature has ended if it does not receive the signal during any 7 minute interval.

9. RESET Button (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings.

10. ON/OFF Button: Operation starts when this button is pressed and stops when the button is pressed again..

11. FAN SPEED Button: Fan speed will be selected in following sequence once pressing this button:

 \vdash AUTO \rightarrow LOW \rightarrow MED \rightarrow HIGH

12. TIME ON Button: For time ON setting. Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

13. TIME OFF Button: For time OFF setting. Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

14. LOCK Button(inner located): When you press the recessed LOCK button, all current settings are locked in and the remote controller does not accept any operation except that of the LOCK. Press again to cancel the LOCK mode.

15. TURBO/FP Button: Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature at cooling or heating operation in the shortest time(if the indoor unit does not support this function, there is no corresponding operation happened when pressing this button.)

Hold down this button for more than 2 seconds during heating operation(only when the setting mode is HEAT) will activate 8°C heating operation mode. The unit will operate at high fan speed with the temperature automatically set to 8°C.


16. LED DISPLAY Button: Press this button to clear the digit display in the air conditioner, press it again to activate it (Not available for the units without LED display window).

3.1.5 RG10A(B2S)/BGEF(Standard for XTREME series &MCA3U-07HRFNX-QRD0W(GA), MCA3U-09HRFNX-QRD0W(GA))

Remote Controller Specifications

Model	RG10A(B2S)/BGEF
Rated Voltage	3.0V (Dry batteries R03/ LR03×2)
Reaching Distance	8m
Environment Temperature Range	-5 °C ~60 °C (23 °F ~140 °F)

Buttons and Functions




Page 122

3.2 LCD Wired Remote Controller


3.2.1 LCD Wired Remote Controller KJR-12B/DP(T) (Standard)

The KJR-12B/DP(T) wired remote controller is standard for Duct type.

i) Buttons and Functions




ii) LCD Screen




iii) Installation

• Dimensions




• Wiring diagram

Refer to the following diagram to wire the Wall mounted type remote control to the indoor unit.




• Installation Diagram

Connect the wire from the display panel of the indoor unit to a connecting cable. Then connect the other side of the connecting cable to the remote control.




Note: Be sure to reserve a length of the connecting wire for periodic maintenance.



Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.


• For exposed mounting, cut holes on four of the sides according to the picture below.




• For shielded wiring, please refer to the picture below.

Embedded switch box wiring

Wiring through the wall




Wiring hole



Wall hole and wiring hole Diameter of wall hole: Φ 2cm

The KJR-120C/TF-E wired remote controller is optional for all types.

i) Buttons and Functions



1. POWER button

Turn on of turn off the unit.

2. MODE(A/B) button

Used to select the operation mode: Auto / Cooling / Drying / Heating / Fan;

Hold to active the operation of auto-lifting panel when off

3. Adjust button

To set temperature, time and timer; set up or down the auto-lifting panel

4. FAN SPEED button

Used to select the fan speed.

5. Up-down airflow direction and swing Button

Press for adjusting the angel of louver, hold for vertical swing; individual louver control for cassette panel

6. Left-righ airflow swing Button

Press for activing the horizontal swing

7. FOLLOW ME(PTC) button

Allows the remote control to act as a remote thermostat and send temperature information from its current location.

- 8. TIMER button
- To set timer on and timer off time of one day
- 9. DELAY/DAY OFF button

To set 1 to 2 hours delay off for each day or a whole day off in a weekly timer schedule

- 10. CONFIRM button
- To confirm an setting or call up the menu
- 11. BACK button

Back to previous operation or superior menu


12. COPY button

Copy timer setting of one day to another in weekly schedule setting

13 Infrared remote receiver (on some models)

Product Features

ii) LCD Screen




- 1 Operation mode indication
- 2 Fan speed indication
- 3 Left-right swing indication
- 4 Up-down swing indication
- 5 Faceplate function indication
- 6 Main unit and secondary unit indication
- 7 Follow me function indication
- 8 PTC function indication

- 9 C° / F° indication
- 10 Temperature display
- 11 Lock indication
- 12 Room temperature indication
- 13 Clock display
- 14 On/Off timer
- 15 Timer display


iii) Installation

• Dimensions




• Wiring diagram


Refer to the following diagram to wire the Wall mounted type remote control to the indoor unit.



• Installation Diagram


Connect the female joint of wires group from the mainboard with the male joint of connective wires group. Then connect the other side of connective wires group with the male joint of wires group leads from wire controller.







Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.

• For exposed mounting, four outletting positions. There are three need cutting.








Cutting place of top side wire outlet

Cutting place of left side wire outlet

Cutting place of right side wire outlet


• For shielded wiring, please refer to the picture below.

Embedded switch box wiring



Wiring hole

Wiring through the wall




Wall hole and wiring hole Diameter of wall hole: Φ2cm

3.2.3 LCD Wired Remote Controller KJR-120G/TF-E(Optional)

The KJR-120G/TF-E wired remote controller is optional for all types.

i) Buttons and Functions



1 MODE button

Used to select the operation mode: Auto / Cooling / Drying / Heating / Fan;

Hold to active the operation of auto-lifting panel when off

2. POWER button

Turn on of turn off the unit.

3. Adjust button

To set temperature, time and timer; set up or down the auto-lifting panel

4. FAN SPEED button

Used to select the fan speed.

5. Swing Button

Press to active vertical swing, hold for horizontal swing

6. TIMER button

To set timer on and timer off time of one day

7.DELAY/DAY OFF button

To set 1 to 2 hours delay off for each day or a whole day off in a weekly timer schedule

8. COPY/FOLLOW ME button

To copy timer setting of one day to another in weekly schedule setting;

To active the follow me function while in normal operation.


9. BACK/TURBO button

Back to previous operation or superior menu

To active turbo mode while in normal operation

10. CONFIRM button

To confirm an setting or call up the superior menu




- 1 Operation mode indication
- 2 Fan speed indication
- 3 Left-right swing indication
- 4 Up-down swing indication
- 5 Faceplate function indication
- 6 Main unit and secondary unit indication
- 7 Follow me function indication

- 8 Turbo/PTC function indication
- 9 C° / F° indication
- 10 Temperature display
- 11 Lock indication
- 12 Room temperature indication
- 13 Clock display
- 14 On/Off timer
- 15 Timer display

iii) Installation


• Dimensions




• Wiring diagram

1) Connection


For Cassette type: The wired controller connects to main control board directly.




For Duct, Ceiling& floor: The wired controller connects to terminal board, terminal board connects to main control board.



2) Address setting




- a. One non-polarity controller can control up to 16 indoor units.
- b. When the non-polarity controller is connected to several units, every air-conditioner in network has only one network address to distinguish each other.
- c. Address code of air-conditioner in LAN is set by code switch ENC1(Duct and Ceiling& Floor) or ADSS(Cassette) of the indoor unit, and the set range is 0-15.
- d. Note: The indoor units are controlled at the same time, not independently. The purpose of setting network address is identify the unit when error occurs.



Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.

• For wiring the indoor unit, there are three methods:

- From the rear;
- From the bottom;
- From the top;
- From the top center.




- 1: Indoor Unit.
- 2: Notch the part for the wiring to pass through with a nipper tool.
- Connect the terminals on the remote controller (HA ,HB), and the terminals of the indoor unit. (HA ,HB). (HA and HB do not have polarity.)

3.3 Centralized Controller

1) Connection

For Light commercial air conditioner with XYE port, it can be directly connected to Centralized Controller (CCM03, CCM09).



2) Address setting

When setting the address, please make sure the unit is powered off. The address can be set from 0 to 63 by the switch. Turn on the unit, then the address will be effective.

SWITCH		TCH FOR CCM UNIT ADDRESS				ESS
S2 + S1	PBCOR	0 7 3 4 5 0 D 3 4 5 0		PBCOA	0 7 3 4 5 g	
ADDRESS	0~15		16~31		1	
Factory Setting		~	-			
\$2 + \$1	ABCOA	1) ₋		PBC04	()	
ADDRESS		32~4	17		48~6	63
Factory Setting						

Note: For light commercial aire conditioner with XYE port, it can be also connected to BMS (Building Management System).

If there is any CAC (central air conditioner) connecting with the central controller at the same time, please set the address from largest (63,62,61...), since the CAC units could obtain address automatically from the smallest (00,01,02...)

3.4 Using the wire controller to set external static pressure

- You can use the unit's automatic airflow adjustment function to set external static pressure.
- Automatic airflow adjustment is the volume of blow-off air that has been automatically adjusted to the quantity rated.

1. Make sure the test run is done with a dry coil. If the coil is not dry, run the unit for 2 hours in FAN ONLY mode to dry the coil.

2. Check that both power supply wiring and duct installation have been completed. Check that any closing dampers are open. Check that the air filter is properly attached to the air suction side passage of the unit.


3. If there is more than one air inlet and outlet, adjust the dampers so that the airflow rate of each air inlet and outlet conforms with the designed airflow rate. Make sure the unit is in FAN ONLY mode. Press and set the airflow adjustment button on the remote control to change the airflow rate from H or L.

4. Set the parameters for automatic airflow adjustment. When the air conditioning unit is off, perform the following steps:

- When the unit is turned off, hold the MODE button and

FAN button down together for three seconds. ("AF" indicator flashes for 3 times.)

- Press " Δ " or " ∇ " to select the AF.



- Press "MODE". The air conditioning unit will then start the fan for airflow automatic adjustment.

After 3 to 6 minutes, the air conditioning unit stops operating once automatic airflow adjustment has finished.



Caution: DO NOT adjust the dampers when automatic airflow adjustment is active.

Caution:

• If there is no change after airflow adjustment in the

ventilation paths, be sure to reset automatic airflow adjustment.

• If there is no change to ventilation paths after airflow adjustment, contact your dealer, especially if this occurs after testing the outdoor unit or if the unit has been moved to a different location.

• Do not use automatic airflow adjustment with remote control, if you are using booster fans, outdoor air processing unit, or a HRV via duct.

• If the ventilation paths have been changed, reset airflow automatic adjustment as described from step 3 onwards.


3.5 Using the wire controller to set airflow rate

When the air conditioning unit is off, perform the following steps:

1.Press"MODE" and "FAN" for three seconds.

2.Press " Δ " or " ∇ " to select the SP.

3.Press "MODE" to set the airflow rate in the range of $0 \sim 4$.



"0": No airflow change

- "1"~"4":Airflow increase progressively
- 4. Press "ON/OFF" to finish the airflow setting.

Page 136

Installation

Contents

Acce	ssories	138
1.	Installation Overview	142
2.	Location Selection	145
3.	Indoor Unit Installation(A6 Duct type)	146
3.	Indoor Unit Installation(Compact cassette type)	148
3.	Indoor Unit Installation(Wall mounted type)	152
4.	Outdoor Unit Installation	160
5.	Drainage Pipe Installation	161
6.	Refrigerant Pipe Installation	163
7.	Vacuum Drying and Leakage Checking	164
8.	Additional Refrigerant Charge	165
9.	Engineering of Insulation	165
10.	Engineering of Electrical Wiring	166
11.	Test Operation	167

Accessories-A6 Duct type:

	Name	Shape	Quantity
	Soundproof / insulation sheath	0	2
Tubing & Fittings	Seal sponge (some models)		1
	Orifice (some models)		1
Drainpipe Fittings	Drain joint (some models)		1
(for cooling & heating)	Seal ring (some models)	0	1
EMC Magnetic Ring (some	Magnetic ring(Wrap the electric wires S1 & S2 (P & Q & E) around the magnetic ring twice)	S1&S2(P&Q&E)	1
models)	Magnetic ring(Hitch on the connective cable between the indoor unit and outdoor unit after installation.)		1
	Manual	-	2~4
	Transfer connector(ϕ 12.7- ϕ 15.9)/(ϕ 0.5in- ϕ 0.63in)(Packed with the indoor unit)		
	NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
Others	Transfer connector($\Phi 6.35 - \Phi 9.52$)/($\Phi 0.25in - \Phi 0.375in$)(Packed with the indoor unit) NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
	Transfer connector(ϕ 9.52- ϕ 12.7)/(ϕ 0.375in- ϕ 0.5in)(Packed with the indoor unit)		
	NOTE: Pipe size may differ from appliance to appliance. To meet different pipe size requirements, sometimes the pipe connections need a transfer connector installed on the outdoor unit.		1 (on some models)
	Connecting wire for display (2m)	-	1(on some models)
	Cord protection rubber ring		1(on some models)
	Display panel *Just for testing purposes only		1(on some models- KJR-120G,KJR-120H)

Optional accessories:

- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.

Accessories-Compact cassette type:

	Name	Shape	Quantity
Indoor unit installation	Installation paper template (some models)		1
Refrigeration Fittings	Soundproof/insulation sheath (some models)		1
	Outlet pipe sheath(some models)		1
Drainpipe Fittings	Outlet pipe clasp(some models)		1
	Drain joint (some models)		1
	Seal ring (some models)		1
	Ceiling hook		4
	Copper nut(some units)	â	
Installation Accessory (some models)	Used to make the connective pipes between indoor and outdoor units.		
(20112110202)	Suspension bolt		4
	Orifice tube (some units)		1
	Anti-shock rubber		1
EMC Magnetic	Magnetic ring (wrap the electric wires S1 & S2 (P & Q & E) around the magnetic ring twice)	S1&S2(P&Q&E)	1
Ring (some models)	Magnetic ring (Hitch it on the connective cable between indoor unit and outdoor unit after installation.)		1
Others	Manual	-	2~4

Optional accessories:

- There are two types of remote controls: wired and wireless.
- Select a remote controller based on customer preferences and requirements and install in an appropriate place.
- Refer to catalogues and technical literature for guidance on selecting a suitable remote controller.


Accessories-wall-mounted type

Name	Shape	Quantity		
Mounting plate		1		
Clip anchor		5		
Mounting plate fixing screw ST3.9 X 25			5	
Remote controller			1	
Fixing screw for remote controller holder ST2.9 x 10		2		
Remote controller holder	Color Color	1	Optional Parts	
Dry battery AAA.LR03		2		
Seal	0			
Drain joint		1(for cooling & heating models only)		
Manual			2~3	
	· · · · · · · · · · · · · · · · · · ·			

	Liquid side	Φ6.35 (1/4in)		
		Φ9.52 (3/8in)	Parts you must purchase.	
Connecting pipe assembly	Gas side	Ф9.52 (3/8in)	Consult the dealer about	
		Φ12.7 (1/2in)	the pipe size.	
		Φ15.9 (5/8in)		

1. Installation Overview


Installation Order-A6 Duct type






Perform a test run


Installation Order-Compact cassette type




Install the indoor unit




Install the outdoor unit




Install the drainpipe




Evacuate the refrigeration system



Connect the wires



Connect the refrigerant pipes




Install the front panel

Perform a test run

Installation Order-Wall mounted type 15cm (5.9in) Ι ⊢ 12cm ⊢– 12cm (4.75in) (4.75in) 2.3m (90.55in) Select Installation Location Determine Wall Hole Position 0 0 o 0 \bigcirc 9999 0 0

Attach Mounting Plate

Drill Wall Hole




2. Location selection

2.1 Unit location selection can refer to installation manual.

2.2 DO NOT install the unit in the following locations:


- Where oil drilling or fracking is taking place.
- Coastal areas with high salt content in the air.
- Areas with caustic gases in the air, such as near hot springs.
- Areas with power fluctuations, such as factories.
- Enclosed spaces, such as cabinets.
- Areas with strong electromagnetic waves.
- Areas that store flammable materials or gas.
- Rooms with high humidity, such as bathrooms or laundry rooms.
- If possible, DO NOT install the unit where it is exposed to direct sunlight.
- 2.3 The minimum distance between the outdoor unit and walls described in the installation guide does not apply to airtight rooms. Be sure to keep the unit unobstructed in at least two of the three directions (M, N, P)




2.4 Rows of series installation

The relations between H, A and L are as follows.


	L	А
I < H	L ≤ 1/2H	25 cm / 9.8" or more
LSH	1/2H < L ≤ H	30 cm / 11.8" or more
L > H	Can not be installed	



DO NOT install the rows of series like following figure.



2.5 If the location is exposed to strong winds (for example: near a seaside), the unit must be placed against the wall to shelter it from the wind. If necessary, use an awning.




DO NOT

Strong wind


3. Indoor Unit Installation(A6 Duct type)

3.1 Service space for indoor unit



3.2 Hang Indoor Unit

1.Please refer to the following diagrams to locate the four positioning screw bolt hole on the ceiling. Be sure to mark the areas where ceiling hook holes will be drilled.



	1 5	
Capacity(Btu/h)	L	Μ
7k/9k/12k	741	360
18k	920	508

2. Install and fit pipes and wires after you have finished installing the main body. When choosing where to start, determine the direction of the pipes to be drawn out.

Especially in cases where there is a ceiling involved, align the refrigerant pipes, drain pipes, and indoor and outdoor lines with their connection points before mounting the unit..


- 3. Install hanging screw bolts.
- 1) Cut off the roof beam.
- 2) Strengthen the point at which the cut was made. Consolidate the roof beam..

4. After you select an installation location, align the refrigerant pipes, drain pipes, as well as indoor and outdoor wires with their connection points before mounting the unit..


5. Drill 4 holes 10cm (4") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.

- 6. Secure the bolt using the included washers and nuts.
- 7. Install the four suspension bolts.

8. Mount the indoor unit with at least two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the washers and nuts provided.



9. Mount the indoor unit onto the hanging screw bolts with a block. Position the indoor unit flat using a level indicator to prevent leaks.




Note: Confirm the minimum drain tilt is 1/100 or more.

3.3 Duct and accessories installation

- 1. Install the filter(optional) according to air inlet size.
- 2. Install the canvas tie-in between the body and duct.

3. The air inlet and air outlet duct should be far enough apart enough to a avoid air passage short-circuit.

4. Connect the duct according to the following diagram.



5. Refer to the following static pressure guidelines when installing the indoor unit.

Capacity(Btu/h)	Static Pressure(Pa)
7k/9k	0-40
12k	0-60
18k	0-100

Change the fan motor static pressure according to external duct static pressure.


NOTE: 1. Do not put the connecting duct weight on the indoor unit.

2. When connecting duct, use inflammable canvas tie-in to prevent vibrating.


3. Insulation foam must be wrapped outside the duct to avoid condensate. An internal duct underlayer can be added to reduce noise, if the end-user requires.

3.4 Adjust the air inlet direction(From rear side to under-side.)


1. Take off ventilation panel and flange,



2. Change the mounting positions of ventilation panel and air return flange .




3. When installing the filter mesh, fit it into the flange as illustrated in the following figure.




NOTE: All the figures in this manual are for demonstration purposes only. The air conditioner you have purchased may be slightly different in design, though similar in shape.

3.5 Fresh air duct installation

Dimension :






3. Indoor Unit Installation(Compact

Cassette Type)







3.2 Hang Indoor Unit

1. Use the included paper template to cut a rectangular hole in the ceiling, leaving at least 1m (39.4") on all sides. The cut hole size should be 4cm(1.6") larger than the body size.

Be sure to mark the areas where ceiling hook holes will be drilled.





- 1 Suspension bolt pitch dimensions
- 2 Body dimensions
- 3 Decoration panel dimensions
- 4 Refrigerant piping
- 5 Suspension bolt (×4)
- 6 Ceiling opening dimensions
- 7 Hanger bracket
- 8 Ceiling board


2. Drill 4 holes 5cm (2") deep at the ceiling hook positions in the internal ceiling. Be sure to hold the drill at a 90° angle to the ceiling.

3. Using a hammer, insert the ceiling hooks into the predrilled holes. Secure the bolt using the included washers and nuts.

4. Install the four suspension bolts




5. Mount the indoor unit. You will need two people to lift and secure it. Insert suspension bolts into the unit's hanging holes. Fasten them using the included washers and nuts



Adjust the position to ensure the gaps between the indoor

unit and the four sides of false ceiling are even. The bottom of the unit should be 24mm / 0.9in higher than ceiling board.


Generally, L should be half the length of the suspension bolt or long enough to prevent the nuts from coming off



CAUTION:

Ensure that the unit is completely level.

The unit is equipped with a built-in drain pump and float switch. If the unit is tilted against the direction of condensate flows (the drainpipe side is raised), the float switch may malfunction and cause water to leak.




NOTE FOR NEW HOME INSTALLATION

When installing the unit in a new home, the ceiling hooks can be embedded in advance. Make sure that the hooks do not come loose due to concrete shrinkage. After installing the indoor unit, fasten the installation paper template onto the unit with bolts (M6X12) to determine in advance the dimension and position of the opening on the ceiling. Follow the instructions above for the remainder of the installation.


3.3 Compact Cassette Panel Installation

3.3.1 Remove the front grille

1. Slide the 2 grille hooks toward the middle of the decoration panel.




2. Hold the grille at a 45° angle, lift it up slightly and detach it from the main body.




3.3.2 Install the panel

1. Align the indicate " \bigtriangleup " on the decoration panel to the indicate " \bigtriangleup " on the unit .

2. Attach the decoration panel to the unit with the supplied screws as shown in figure below.




3. After installing the panel, ensure that there is no space between the unit body and decoration panel. Otherwise air may leak through the gap and cause dewdrop.




3.3.3 Mount the grille

Ensure that the buckles at the back of the grille be properly seated in the groove of the panel.




3.3.4 Connect the two wires of the panel to the main board of the unit.




3.3.5 Fasten the control box lid with two screws .



3.3.6 Close the front grille, and close the two grille hooks.



3.1 Service space for indoor unit



3.2 Attach mounting plate to wall

• The mounting plate is the device on which you will mount the indoor unit.

1. Remove the screw that attaches the mounting plate to the back of the indoor unit.

2. Place the mounting plate against the wall in a location that meets the standards in the Select Installation Location step. (See Mounting Plate Dimensions for detailed information on mounting plate sizes.)

3. Drill holes for mounting screws in places that:

- have studs and can support the weight of the unit.
- correspond to screw holes in the mounting plate.

4. Secure the mounting plate to the wall with the screws provided.

5. Make sure that mounting plate is flat against the wall.


• Mounting plate dimensions


Different models have different mounting plates. In order to ensure that you have ample room to mount the indoor unit, the diagrams to the right show different types of mounting plates along with the following dimensions:

- 1. Width of mounting plate
- 2. Height of mounting plate
- 3. Width of indoor unit relative to plate
- 4. Height of indoor unit relative to plate

5. Recommended position of wall hole (both to the left and right of mounting plate)


6. Relative distances between screw holes








For Aurora series:



9K Model



and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.

3.3 Drill wall hole for connective piping


You must drill a hole in the wall for refrigerant piping, the drainage pipe, and the signal cable that will connect the indoor and outdoor units.

1. Determine the location of the wall hole based on the position of the mounting plate. Refer to Mounting Plate Dimensions on the next page to help you determine the optimal position. The wall hole should have a 65mm (2.5in) diameter at least, and at a slightly lower angle to facilitate drainage.

2. Using a 65mm (2.5in) or 90mm(3.54in) (depending on models)core drill, drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 5mm to 7mm (0.2-0.27in). This will ensure proper water drainage.

3. Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.

NOTE: When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.



3.4 Prepare refrigerant piping

The refrigerant piping is inside an insulating sleeve attached to the back of the unit. You must prepare the piping before passing it through the hole in the wall. Refer to the Refrigerant Piping Connection section of this manual for detailed instructions on pipe flaring and flare torque requirements, technique, etc.

1. Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit.

2. If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor

unit, remove the plastic knock-out panel from that side of the unit. This will create a slot through which your piping can exit the unit. Use needle nose pliers if the plastic panel is too difficult to remove by hand.

3. Groove has been made in the knock-out panel in order to cut it conveniently. The size of the slot is determined by the diameter of piping.

4. Use scissors to cut down the length of the insulating sleeve to reveal about 15cm (6in) of the refrigerant piping. This serves two purposes:


- To facilitate the Refrigerant Piping Connection process.
- To facilitate Gas Leak Checks and enable you to check for dents.

5. If existing connective piping is already embedded in the wall, proceed directly to the Connect Drain Hose step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. Refer to the Refrigerant Piping Connection section of this manual for detailed instructions.

6. Based on the position of the wall hole relative to the mounting plate, determine the necessary angle of your piping.


7. Grip the refrigerant piping at the base of the bend.

8. Slowly, with even pressure, bend the piping towards the hole. Do not dent or damage the piping during the process.



NOTE: Refrigerant piping can exit the indoor unit from four different angles:

- Left-hand side
- Left rear
- Right-hand side
- Right rear



Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.

3.5 Connect drain hose

By default, the drain hose is attached to the left hand side of unit (when you're facing the back of the unit). However, it can also be attached to the right-hand side.

1. To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit.

2. Attach drain hose extension (purchased separately) to the end of drain hose.

3. Wrap the connection point firmly with Teflon tape to ensure a good seal and to prevent leaks.


4. For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.

5. Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.

NOTE ON DRAIN HOSE PLACEMENT:

- DO NOT kink the drain hose.
- DO NOT create a water trap.
- DO NOT put the end of drain hose in water or a

container that will collect water.



Make sure there are no kinks or dent in drain hose to ensure proper drainage.

3.6 Connect signal cable

3.6.1 Before performing electrical work, read these regulations

1. All wiring must comply with local and national electrical codes, and must be installed by a licensed electrician.

2. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.

3. If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.

4. Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.

5. If connecting power to fixed wiring, install a surge protector and main power switch with a capacity of 1.5 times the maximum current of the unit.

6. If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 1/8in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.

7. Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.

8. Make sure to properly ground the air conditioner.

9. Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.

10. Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.

11. If the unit has an auxiliary electric heater, it must be installed at least 1 meter (40in) away from any combustible

materials.

12. BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

3.6.2 Connect signal cable

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

Cable Types:


- Indoor Power Cable (if applicable): H05VV-F or H05V2V2-F
- Outdoor Power Cable: H07RN-F
- Signal Cable: H07RN-F

For Aurora series & Forest series:

1. Prepare the cable for connection:

- Using wire strippers, strip the rubber jacket from both ends of signal cable to reveal about 40mm (1.57in) of the wires inside.
- Strip the insulation from the ends of the wires.
- Using wire crimper, crimp u-type lugs on the ends of the wires.
- 2. Open front panel of the indoor unit.

3. Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.



4. Unscrew the cable clamp below the terminal block and place it to the side.

5. Facing the back of the unit, remove the plastic panel on the bottom left-hand side.

6. Feed the signal wire through this slot, from the back of the unit to the front.


7. Facing the front of the unit, match the wire colors with the labels on the terminal block, connect the u-lug and and firmly screw each wire to its corresponding terminal. 8. After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.

9. Replace the wire cover on the front of the unit, and the plastic panel on the back.

For All Easy series:

1. Open front panel of the indoor unit by loosen the screws according to picture below, which provide big space for wiring connection.

2. Open the wire box cover to connect the cable.



3.Unscrew the cable clamp below the terminal block and place it to the side.

4.Facing the back of the unit, remove the plastic panel on the bottom left-hand side.

5. Feed the signal wire through this slot, from the back of the unit to the front.

6. Facing the front of the unit, connect the wire according to the indoor unit's wiring diagram, connect the u-lug and firmly screw each wire to its corresponding terminal.


7. After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.

8. Replace the wire cover on the front of the unit, and the plastic panel on the back.

For XTREME series:

1. Open front panel of the indoor unit.

2.Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.



3.Unscrew the cable clamp below the terminal block and place it to the side.

4. Facing the back of the unit, remove the plastic panel on the bottom left-hand side.

5.Feed the signal wire through this slot, from the back of the unit to the front.

6.Facing the front of the unit, connect the wire according to the indoor unit's wiring diagram, connect the u-lug and firmly screw each wireto its corresponding terminal.

7. After checking to make sure every connectionis secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.

8. Replace the wire cover on the front of the unit, and the plastic panel on the back.

NOTE:

• Choose the right cable size

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.

• Take note of fuse specifications

The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board, such as: Indoor

unit: T3.15AL/250VAC, T5AL/250VAC, T3.15A/250VAC, T5A/250VAC, T20A/250VAC, T30A/250VAC, etc.(The fuse is made of ceramic.)

• Pay attention to live wire

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.

- All wiring must performed strictly in accordance with the wiring diagram located on the inside of the indoor unit's wire cover.
- Do not mix up live and null wires.


This is dangerous, and can cause the air conditioning unit to malfunction.

• The wiring connection process may differ slightly between units.

3.7 Wrap piping and cables

Before passing the piping, drain hose, and the signal cable through the wall hole, you must bundle them together to save space, protect them, and insulate them.

1. Bundle the drain hose, refrigerant pipes, and signal cable according to the picture below:



2. Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.

3. Using insulation tape, wrap the signal wire, refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled in accordance with the picture above.

NOTE:

• Drain hose must be on bottom

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.

• Do not intertwine signal cable with other wires

While bundling these items together, do not intertwine or cross the signal cable with any other wiring

• Do not wrap ends of piping

When wrapping the bundle, keep the ends of the piping

unwrapped. You need to access them to test for leaks at the end of the installation process.

3.8 Mount indoor unit

3.8.1 If you installed new connective piping to the outdoor unit, do the following:

1. If you have already passed the refrigerant piping through the hole in the wall, proceed to **step 4**.

2. Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.

3. Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.

4. Hook the top of the indoor unit on the upper hook of the mounting plate.

5. Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.

6. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.

7. Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.


3.8.2 If refrigerant piping is already embedded in the wall, do the following:

For Aurora series, Forest series&XTREME series:

1. Hook the top of the indoor unit on the upper hook of the mounting plate.


• Unit is adjustable

Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit. If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 30-50mm (1.25-1.95in), depending on the model.



Move to left or right

2. Use the holder in the mounting plate to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose.



3. Connect drain hose and refrigerant piping (refer to Refrigerant Piping Connection section of this manual for instructions).

4. Keep pipe connection point exposed to perform the leak test (refer to Electrical Checks and Leak Checks section of this manual).

5. After the leak test, wrap the connection point with insulation tape.

6. Remove the bracket or wedge that is propping up the unit.

7. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.

For All Easy series:

Step 1:Hook the indoor unit on the mounting plate:


1. Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit.If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 30-50mm (1.25-1.95in), depending on the model.



Move to left or right


Step 2: Prepare refrigerant piping:

1. Disassemble the louver:



2. Open and fix the position of the panel

Firstly, unscrew the two screws showed in the picture below, then open the panel, and fix the position of the panel by the latch.



3. Use the holder in the mounting plate to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose.

Step 3. Connect drain hose and refrigerant piping (refer to Refrigerant Piping Connection section of this manual for instructions).

Step 4. Keep pipe connection point exposed to perform the leak test (refer to Electrical Checks and Leak Checks section of this manual).

Step 5. After the leak test, wrap the connection point with insulation tape.


Step 6. Remove the bracket or wedge that is propping with insulation tape.

Step 7. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.


Page 158

4. Outdoor unit installation

4.1 Service space for outdoor unit




4.2 Bolt pitch



Model	А	В	D
M2OG-14HFN8-Q M2OC-18HFN8-Q M2OD-18HFN8-Q	514	340	333
M3OF-21HFN8-Q M3OE-27HFN8-Q M3OF-27HFN8-Q	540	350	363
M4OE-28HFN8-Q M4OB-36HFN8-Q	670	102	110
M50D-42HFN8-Q M50E-42HFN8-Q	673	403	410
M2OH-14HFN8-Q M2OE-18HFN8-Q	511	317	554
M3OG-21HFN8-Q M3OA-27HFN8-Q	663	354	673

4.3 Install Outdoor Unit

Fix the outdoor unit with anchor bolts(M10)



Cation

Since the gravity center of the unit is not at its physical center, so please be careful when lifting it with a sling.

Never hold the inlet of the outdoor unit to prevent it from deforming.

Do not touch the fan with hands or other objects.

Do not lean it more than 45, and do not lay it sidelong.

Make concrete foundation according to the specifications of the outdoor units.

Fasten the feet of this unit with bolts firmly to prevent it from collapsing in case of earthquake or strong wind.

5. Drainage Pipe Installation

Install the drainage pipe as shown below and take measures against condensation. Improperly installation could lead to leakage and eventually wet furniture and belongings.

5.1 Installation principle

- Ensure at least 1/100 slope of the drainage pipe
- Adopt suitable pipe diameter
- Adopt nearby condensate water discharge

5.2 Key points of drainage water pipe installation

1. Considering the pipeline route and elevation.

- Before installing condensate water pipeline, determine its route and elevation to avoid intersection with other pipelines and ensure slope is straight.
- 2. Drainage pipe selection
 - The drainage pipe diameter shall not small than the drain hose of indoor unit
 - According to the water flowrate and drainage pipe slope to choose the suitable pipe, the water flow-rate is decided by the capacity of indoor unit.

Relationship between water flowrate and capacity of indoor unit

Capacity (kBtu)	Water flowrate (l/h)
12	2.4
18	4
24	6
30	7
36	8
42	10
48	12
55	14

According to the above table to calculate the total water flowrate for the confluence pipe selection.

For horizontal drainage pipe (The following table is for reference)

PVC	Reference value of inner diameter of	Allov maximu flowra	m water	Remark
pipe	pipe (mm)	Slope 1/50	Slope 1/100	
PVC25	20	39	27	For branch
PVC32	25	70	50	pipe
PVC40	31	125	88	Could be used
PVC50	40	247	175	for confluence
PVC63	51	473	334	pipe

Attention: Adopt PVC40 or bigger pipe to be the main pipe.

For Vertical drainage pipe (The following table is for reference)

PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (l/h)	Remark
PVC25	20	220	For branch
PVC32	25	410	pipe
PVC40	31	730	
PVC50	40	1440	Could be
PVC63	51	2760	used for confluence
PVC75	67	5710	pipe
PVC90	77	8280	


Attention: Adopt PVC40 or bigger pipe to be the main pipe.

3. Individual design of drainage pipe system


- The drainage pipe of air conditioner shall be installed separately with other sewage pipe, rainwater pipe and drainage pipe in building.
- The drainage pipe of the indoor unit with water pump should be apart from the one without water pump.

4. Supporter gap of drainage pipe


- In general, the supporter gap of the drainage pipe horizontal pipe and vertical pipe is respectively 1m~1.5m and 1.5m~2.0m.
- Each vertical pipe shall be equipped with not less than two hangers.
- Overlarge hanger gap for horizontal pipe shall create bending, thus leading to air block.



5. The horizontal pipe layout should avoid converse flow or bad flow




- The correct installation will not cause converse water flow and the slope of the branch pipes can be adjusted freely
- The false installation will cause converse water flow and the slope of the branch pipe can not be adjusted.
- 6. Water storage pipe setting
 - If the indoor unit has high extra static pressure and without water pump to elevate the condensate water, such as high extra static pressure duct unit, the water storage pipe should be set to avoid converse flow or blow water phenomena.




- 7. Lifting pipe setting of indoor unit with water pump
- The length of lifting pipe should not exceed 750mm.
- The drainage pipe should be set down inclined after the lifting pipe immediately to avoid wrong operation of water level switch.

• Refer the following picture for installation reference.



- 8. Blowhole setting
 - For the concentrated drainage pipe system, there should design a blowhole at the highest point of main pipe to ensure the condensate water discharge smoothly.
 - The air outlet shall face down to prevent dirt entering pipe.
 - Each indoor unit of the system should be installed it.
 - The installation should be considering the convenience for future cleaning.



9. The end of drainage pipe shall not contact with ground directly.


5.3 Drainage test

- 1. Water leakage test
 - After finishing the construction of drainage pipe system, fill the pipe with water and keep it for 24 hours to check whether there is leakage at joint section.
- 2. Water discharge test

Check that the drainpipe is unhindered.

This test should be performed on newly built houses before the ceiling is paved.


2.1 Units without a pump



- Fill the water pan with 2 liters of water.
- Check that the drainpipe is unhindered
- .2.2 Units with a pump

1. Remove the test cover.

• Fill the water pan with 2 liters of water.



2. Turn on the unit in COOLING mode. You will hear the drain pump.Check whether the water is discharged properly (a 1-minute lag is possible, depending on the length of the drain pipe), Check whether water leaks from

the joints.

- 3. Turn off the air conditioner and put the cap back on.
 - After turn off the air conditioner 3 minutes, check whether there is anything abnormal. If drainage pipes have not been distributed properly, over back-flow water shall cause the flashing of alarm indicator at remote-controlled receiving board and

even water shall run over the water collector.

• Continuously infusing water until water level alarmed, check whether the drainage pump could discharge water at once. If water level does not decline under warning water level 3 minutes later, it shall cause shutdown of unit. When this situation happens, the normal startup only can be recovered by turning down power supply and eliminating accumulated water.

Note: Drain plug at the main water-containing plate is used for eliminating accumulated water in watercontaining plate when maintaining air conditioner fault. During normal operation, the plug shall be filled in to prevent leakage.

5.4 Insulation work of drainage pipe

Refer the introduction to the insulation engineering parts.


6. Refrigerant Pipe Installation

6.1 Maximum length and drop height

Ensure that the length of the refrigerant pipe and the drop height between the indoor and outdoor units meets the requirements shown in the following table.

	M2OG-14HFN8-Q M2OC-18HFN8-Q M2OD-18HFN8-Q M2OH-14HFN8-Q M2OH-14HFN8-Q	M3OE-27HFN8-Q M3OF-27HFN8-Q M3OF-21HFN8-Q M3OG-21HFN8-Q M3OA-27HFN8-O	M4OB-36HFN8-Q M4OE-28HFN8-Q	M5OD-42HFN8-Q M5OE-42HFN8-Q
Max. length for all rooms	40	60	80	80
Max. length for one indoor unit	25	30	35	35
Max. height different between IDU and ODU	15	15	15	15
Max. height different between IDUs	10	10	10	10


• When installing multiple indoor units with a single outdoor unit, ensure that the length of the refrigerant pipe and the drop height between the indoor and outdoor units meet the requirements illustrated in the following diagram:



6.2 The procedure of connecting pipes

1. Choose the pipe size according to the specification table.

- 2.Confirm the cross way of the pipes.
- 3. Measure the necessary pipe length.
- 4.Cut the selected pipe with pipe cutter
 - Make the section flat and smooth.



5. Insulate the copper pipe

- Before test operation, the joint parts should not be heat insulated.
- 6. Flare the pipe
 - Insert a flare nut into the pipe before flaring the pipe
 - According to the following table to flare the pipe.

Pipe diameter	Flare dimension A (mm/inch)		Elara chana
(inch(mm))	Min	Max	Flare shape
1/4" (6.35)	8.4/0.33	8.7/0.34	
3/8" (9.52)	13.2/0.52	13.5/0.53	90°±4
1/2" (12.7)	16.2/0.64	16.5/0.65	A 4
5/8" (15.9)	19.2/0.76	19.7/0.78	R0.4~0.8
3/4" (19)	23.2/0.91	23.7/0.93	
7/8" (22)	26.4/1.04	26.9/1.06	

- After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.
- 7. Drill holes if the pipes need to pass the wall.

8. According to the field condition to bend the pipes so that it can pass the wall smoothly.

9. Bind and wrap the wire together with the insulated pipe if necessary.

- 10. Set the wall conduit
- 11. Set the supporter for the pipe.

12. Locate the pipe and fix it by supporter

- For horizontal refrigerant pipe, the distance between supporters should not be exceed 1m.
- For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.

13. Connect the pipe to indoor unit and outdoor unit by using two spanners.

• Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the

bellmouthing, and too small torque may cause leakage. Refer the following table for different pipe connection.

Dino Diamatar	Torque	Skatch man
Pipe Diameter	N.m(lb.ft)	Sketch map
1/4" (6.35)	15~16 (11~11.8)	
3/8" (9.52)	25~26 (18.4~19.18)	
1/2" (12.7)	35~36 (25.8~26.55)	
5/8" (15.9)	45~47 (33.19~34.67)	
3/4" (19)	65~67 (47.94~49.42)	
7/8" (22)	75-85 (55.3-62.7)	

7. Vacuum Drying and Leakage Checking

7.1 Purpose of vacuum drying

• Eliminating moisture in system to prevent the phenomena of ice-blockage and copper oxidation.

Ice-blockage shall cause abnormal operation of system, while copper oxide shall damage

compressor.

• Eliminating the non-condensable gas (air) in system to prevent the components oxidizing, pressure fluctuation and bad heat exchange during the operation of system.

7.2 Selection of vacuum pump

- The ultimate vacuum degree of vacuum pump shall be -756mmHg or above.
- Precision of vacuum pump shall reach 0.02mmHg or above.

7.3 Operation procedure for vacuum drying

Due to different construction environment, two kinds of vacuum drying ways could be chosen, namely ordinary vacuum drying and special vacuum drying.

7.0.1 Ordinary vacuum drying

1. When conduct first vacuum drying, connect pressure gauge to the infusing mouth of gas pipe and liquid pipe, and keep vacuum pump running for 1hour (vacuum degree of vacuum pump shall be reached -755mmHg).

2. If the vacuum degree of vacuum pump could not reach

-755mmHg after 1 hour of drying, it indicates that there is moisture or leakage in pipeline system and need to go on with drying for half an hour.

3. If the vacuum degree of vacuum pump still could not reach -755mmHg after 1.5 hours of drying, check whether there is leakage source.

4 . Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

7.0.2 Special vacuum drying

The special vacuum drying method shall be adopted when:

1. Finding moisture during flushing refrigerant pipe.

2. Conducting construction on rainy day, because rain water might penetrated into pipeline.

3. Construction period is long, and rain water might penetrated into pipeline.

4. Rain water might penetrate into pipeline during construction.

Procedures of special vacuum drying are as follows:

1. Vacuum drying for 1 hour.

2. Vacuum damage, filling nitrogen to reach 0.5Kgf/cm2 .

Because nitrogen is dry gas, vacuum damage could achieve the effect of vacuum drying, but this method could not achieve drying thoroughly when there is too much moisture. Therefore, special attention shall be drawn to prevent the entering of water and the formation of condensate water.

3. Vacuum drying again for half an hour.

If the pressure reached -755mmHg, start to pressure leakage test. If it cannot reached the value, repeat vacuum damage and vacuum drying again for 1 hour.

4. Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

< Page 164 🕨

8. Additional Refrigerant Charge

- After the vacuum drying process is carried out, the additional refrigerant charge process need to be performed.
- The outdoor unit is factory charged with refrigerant. The additional refrigerant charge volume is decided by the diameter and length of the liquid pipe between indoor and outdoor unit. Refer the following formula to calculate the charge volume.

Diameter of liquid pipe (mm)	Formula
	V=12g/m×((Total pipe
6.35	length - pre-charge
	pipe lengthxN)) V=24g/m×((Total pipe
9.52	length - pre-charge
	pipe lengthxN))

The pre-charge pipe length is 7.5m.

Note:

- Refrigerant may only be charged after performed the vacuum drying process.
- Always use gloves and glasses to protect your hands and eyes during the charge work.
- Use electronic scale or fluid infusion apparatus to weight refrigerant to be recharged. Be sure to avoid extra refrigerant charged, it may cause liquid hammer of the compressor or protections.
- Use supplementing flexible pipe to connect refrigerant cylinder, pressure gauge and outdoor unit. And The refrigerant should be charged in liquid state. Before recharging, The air in the flexible pipe and manifold gauge should be exhausted.
- After finished refrigerant recharge process, check whether there is refrigerant leakage at the connection joint part.(Using gas leakage detector or soap water to detect).

9. Engineering of Insulation

9.1 Insulation of refrigerant pipe

1. Operational procedure of refrigerant pipe insulation

Cut the suitable pipe \rightarrow insulation (except joint section) \rightarrow flare the pipe \rightarrow piping layout and connection \rightarrow vacuum drying \rightarrow insulate the joint parts

2. Purpose of refrigerant pipe insulation


- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out insulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- Temperature of gas pipe is very high (generally 50-100° C) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.

3. Insulation material selection for refrigerant pipe

- The burning performance should over 120° C
- According to the local law to choose insulation materials
- The thickness of insulation layer shall be above 10mm.If in hot or wet environment place, the layer of insulation should be thicker accordingly.

4. Installation highlights of insulation construction

• Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- The insulation material at the joint pipe shall be 5~10cm longer than the gap of the insulation material.
- The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- The linking part should be use glue to paste together
- Be sure not bind the insulation material over-tight, it may extrude out the air in the material to cause bad

insulation and cause easy aging of the material.

9.2 Insulation of drainage pipe

1. Operational procedure of refrigerant pipe insulation

Select the suitable pipe \rightarrow insulation (except joint section) \rightarrow piping layout and connection \rightarrow drainage test \rightarrow insulate the joint parts

2. Purpose of drainage pipe insulation

The temperature of condensate drainage water is very low. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

3. Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- Thickness of insulation layer is usually above 10mm.
- Use specific glue to paste the seam of insulation material, and then bind with adhesive tape. The width of tape shall not be less than 5cm. Make sure it is firm and avoid dew.

4. Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- There should be no insulation gap between the insulation material.

10. Engineering of Electrical Wiring

10.1 Highlights of electrical wiring installation

- All field wiring construction should be finished by qualified electrician.
- Air conditioning equipment should be grounded according to the local electrical regulations.
- Current leakage protection switch should be installed.
- Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm gap.
- According to table in indoor part named "the specification of the power" to choose the wiring, make sure the selected wiring not small than the date showing in the table.
- Select different colors for different wire according to relevant regulations.
- Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.
- You must first choose the right cable size before preparing it for connection. Be sure to use H07RN-F cables.

Table: Minimum Cross-Sectional Area able of Power and Signal Cables

Rated Current of Appliance (A)	Nominal Cross-Sectional Area(mm ²)
≤ 6	0.75
6 - 10	1
10 - 16	1.5
16 - 25	2.5
25 - 32	4
32 - 45	6

11. Test Operation

11.1 The test operation must be carried out after the entire installation has been completed.

11.2 Please confirm the following points before the test operation.

- The indoor unit and outdoor unit are installed properly.
- Tubing and wiring are correctly completed.
- The refrigerant pipe system is leakage-checked.
- The drainage is unimpeded.
- The ground wiring is connected correctly.
- The length of the tubing and the added stow capacity of the refrigerant have been recorded.
- The power voltage fits the rated voltage of the air conditioner.
- There is no obstacle at the outlet and inlet of the outdoor and indoor units.
- The gas-side and liquid-side stop values are both opened.
- The air conditioner is pre-heated by turning on the power.

11.3 Test operation

1. Open both the liquid and gas stop valves.

2. Turn on the main power switch and allow the unit to warm up.

3. Set the air conditioner to COOL mode, and check the following points.

Indoor unit

- Whether the switch on the remote controller works well.
- Whether the buttons on the remote controller works well.
- Whether the air flow louver moves normally.
- Whether the room temperature is adjusted well.
- Whether the indicator lights normally.
- Whether the temporary buttons works well.
- Whether the drainage is normal.
- Whether there is vibration or abnormal noise during operation.

Outdoor unit

- Whether there is vibration or abnormal noise during operation.
- Whether the generated wind, noise, or condensed of by the air conditioner have influenced your neighborhood.
- Whether any of the refrigerant is leaked.

Drainage Test

a. Ensure the drainpipe flows smoothly. New buildings should perform this test before finishing the ceiling.

b. Remove the test cover. Add 2000ml of water to the tank through the attached tube.

c.Turn on the main power switch and run the air conditioner in COOL mode.

d. Listen to the sound of the drain pump to see if it makes any unusual noises.

e. Check to see that the water is discharged. It may take up to one minute before the unit begins to drain depending on the drainpipe.

f. Make sure that there are no leaks in any of the piping.

g. Stop the air conditioner. Turn off the main power switch and reinstall the test cover.

If ambient temperature is below 17°C (63°F)

You can't use the remote controller to turn on the COOL function when the ambient temperature is below 17°C. In this instance, you can use the MANUAL CONTROL button to test the COOL function.

1. Lift the front panel of the indoor unit, and raise it until it clicks in place.

2. The MANUAL CONTROL button is located on the righthand side of the display box. Press it two times to select the COOL function.

3. Perform Test Run as normal.

Static Pressure Design

Contents

1.	Introduction	169
2.	Charts For Friction Losses in Round Ducts	169
3.	Dynamic Losses	170
4.	Corresponding Relation Between Rectangular Duct and Round Duct	171
5.	Method For Duct Calculation	172
6.	Unit Conversion	172
7.	Recommended Outlet Velocity For Different Occasions	172

1. Introduction


Duct system losses are the irreversible transformation of mechanical energy into heat. The two types of losses are (1) friction losses and (2) dynamic losses.

Friction losses are due to fluid viscosity and result from momentum exchange between molecules (in laminar flow) or between individual particles of adjacent fluid layers moving at different velocities (in turbulent flow). Friction losses occur along the entire duct length.

Dynamic losses result from flow disturbances caused by duct mounted equipment and fittings (e.g., entries, exits, elbows, transitions, and junctions) that change the airflow path's direction or area.


2. Charts For Friction Losses In Round Ducts

Fluid resistance caused by friction in round ducts can be determined by the friction chart. (based on galvanized sheet)



3. Dynamic Losses

For dynamic losses, please refer to below image.



Note: W Shows a diameter of round duct or long side length of the rectangular duct.

Circular Duct	4	5	6	7	8	9	10	12	14	16	18	ngular 20	Duca, 22	in. 24	26	28	30	32	34	36
Diameter, -	4	2	0	/	0	9	25325	1080	12.725	AVS2855	1805120	0.0761900	r Dudb	1.000	20	20	50	52	54	50
in.	-						Leng	jin Au	Jacent	. Side d	n necta	ingula		, m.						
5 5.5	5 6	5																		
6	8	6																		
6.5 7	9 11	7 8	6 7																	
7.5	13	10	8	7																
8 8.5	15	11	9	8																
8.5 9	17 20	13 15	10 12	9 10	8															
9.5	22	17	13	11	9															
10 10.5	25 29	19 21	15 16	12 14	10 12	9 10														
10.5	32	23	18	15	13	11	10													
11.5		26	20	17	14	12	11													
12 12.5		29 32	22 24	18 20	15 17	13 15	12 13													
13		35	27	22	18	16	14	12												
13.5 14		38	29 32	24 26	20 22	17 19	15 17	13 14												
14			32	28	22	20	18	14												
15			38	30	25	22	19	16	14											
16 17			45	36 41	30 34	25 29	22 25	18 20	15 17	16										
18				47	39	33	29	23	19	17										
19 20				54	44 50	38 43	33 37	26 29	22 24	19 21	18 19									
21					57	48	41	33	27	23	20									
22					64	54	46	36	30	26	23	20								
23 24						60 66	51 57	40 44	33 36	28 31	25 27	22 24								
25							63	49	40	34	29	26	24							
26 27							69 76	54 59	44 48	37 40	32 35	28 31	26 28	24 25						
28							/0	64	52	43	38	33	30	27	26					
29								70	56	47	41	36	32	29	27	20				
30 31								76 82	61 66	51 55	44 47	39 41	35 37	31 34	29 31	28 29				
32								89	71	59	51	44	40	36	33	31				
33 34								96	76 82	64 68	54 58	48 51	42 45	38 41	35 37	33 35	30 32			
35									88	73	62	54	48	44	40	37	34	32		
36 37									95 101	78 83	67 71	58	51 55	46 49	42	39 41	36 38		34	
38									108	89	76	62 66	58	52	45 47			36 38		5
39										95	80	70	62	55	50	46	43	40	37	
40 41										101 107	85 91	74 78	65 69	58 62	53 56	49 51	45 47	42 44	39 41	3
42										114	96	83	73	65	59	54	50	46	44	ł
43 44										120	102 107	88 93	77 81	69 73	62 66	57 60	53 55	49 51	46 48	4
45											113	98	86	76	69	63	58	54	50	
46											120	103	90	80	72	66	61	56	53	4
47 48											126 133	108 114	95 100	84 89	76 80	69 73	64 67	59 62	55 58	
49											140	120	105	93	84	76	70	65	60	5
50 51											147	126 132	110 115	98 102	88 92	80 83	73 76	68 71	63 66	
52												139	121	107	96	87	80	74	69	6
53												145	127	112	100	91	83	77	71	
54 55												152	133 139	117 123	105 110	95 99	87 91	80 84	74 78	7.
56													145	128	114	104	95	87	81	
57 58													151 158	134 139	119 124	108 112	98 102	91 94	84 87	81
59													165	145	130	117	107	98	91	
60													172	151	135	122	111	102	94	i

4. Corresponding Relation Between Rectangular Duct and Round Duct

5. Method For Duct Calculation (equal friction method)

1)Draw schematic view of the duct system.

1)Make notes for air volume and mark clearly the elbow, the branch parts, the air discharge outlet.

1)Select one main ducting route (where the maximum static pressure loss occurs).

1)Select the air velocity for the main duct in accordance with the desirable air velocity.

	Typical design velocity (m/s)								
Main duct	Residence	Public building	Factory						
Main duct	3.5~6.0	5.0~8.0	6.0~11.0						

1)Since the velocity and air volume are fixed for main duct, then use the Friction loss chart to find standard friction loss.

2)Use air volume and friction loss to find corresponding duct size and velocity for each part of main duct through Frictions loss chart.

3)Find the dynamic loss of main ducting route according to the velocity. and type of special fittings (elbows, junctions, regulating flaps, etc.)

4)Obtain the duct size and velocity of each branch duct based on the air volume and the same standard friction loss as for the main duct.

5)Find the dynamic loss of branch duct.

6)Calculate the total pressure loss.

6. Unit Conversion

- 1 inch water=248.8 N/m² (Pa)=0.0361 lb/in² (psi)=25.4 kg/cm²=0.0739 in mercury
- 1 ft³/min (cfm)=1.7 m³/h
- 1 ft/min=5.08*10-3 m/s
- 1 inch=2.54 cm=0.0254m=0.08333ft

7. Recommended Outlet Velocity For Different Occasion

The permissible sound level and correspondingly maximum air velocity, is determined by the occasion.

Noise / dB(A)	Occasion	Maximum velocity / m/s
25	Studio, recording room	2
35	Cinema, hospital, library	3
40	Office, school, hotel	4
46	Bank, public hall	5
50	Store, post office	6
70	Factory	10